


INSTALLATION MANUAL



> STS400™



Datalogic Automation S.r.l.
Via Lavino, 265
40050 - Monte S. Pietro
Bologna - Italy

STS400™ Installation Manual

Ed.: 09/2015

© 2013 - 2015 Datalogic Automation S.r.l. ♦ ALL RIGHTS RESERVED. ♦ Protected to the fullest extent under U.S. and international laws. Copying, or altering of this document is prohibited without express written consent from Datalogic Automation S.r.l.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

Matrix 410, ID-NET, VisiSet and X-PRESS are trademarks of Datalogic Automation S.r.l. All other brand and product names mentioned herein are for identification purposes only and may be trademarks or registered trademarks of their respective owners.

Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material.

821002493 (Rev. C)

CONTENTS

REFERENCES	v
Conventions.....	v
Reference Documentation.....	v
Support Through The Website.....	v
Patents.....	v
 COMPLIANCE.....	 vi
EMC Compliance.....	vi
Power Supply.....	vi
LED Compliance.....	vi
CE Compliance.....	vi
FCC Compliance	vi
 HANDLING.....	 vii
 GENERAL VIEW	 viii
 1 INTRODUCTION	 1
1.1 STS400™ - Solution for Tires Sorting	1
1.2 Terminology	2
1.3 STS400™ Feasibility Requirements.....	3
1.3.1 Extracting Tire Size From Tire Sidewall Markings	5
1.4 STS400™ Model Descriptions.....	6
1.5 Power Requirements	6
1.6 STS400™ Accessories.....	7
 2 INSTALLATION	 8
2.1 STS400™ Supporting Frame	8
2.1.1 Frame Width	9
2.1.2 Frame Length	9
2.1.3 Frame Height.....	10
2.1.4 Frame Bill Of Materials	11
2.2 Mechanical Dimensions.....	12
2.3 Mounting Distance (DOF).....	20
2.3.1 STS400-004, STS400-005, STS400-006, STS400-007, STS400-008.....	20
2.3.2 STS400-015, STS400-016, STS400-017, STS400-018	21
2.3.3 STS400-105, STS400-106, STS400-107, STS400-108	21
2.3.4 STS400-115, STS400-116, STS400-117, STS400-118	22
2.3.5 STS400-205, STS400-206	22
2.3.6 STS400-305, STS400-306	23
2.4 Supporting Profile Height Adjustment.....	24
2.5 STS400™ Main Plate Mounting	25
2.5.1 STS400™ Plate Support Assembly Positioning for Odd Number of Readers	27
2.6 Presence Sensor Positioning.....	29
 3 ELECTRICAL CONNECTIONS	 32
3.1 STS400™ Wiring Diagram	32
3.2 CBX Connection Box Pinout.....	33
3.3 Power Supply.....	34
3.3.1 STS400-1xx Models	34
3.4 M12-D 4-Pin Connector (Ethernet)	34
3.5 Main Serial Interface.....	35

3.5.1	RS232 Interface	36
3.5.2	RS485 Full-Duplex Interface	37
3.6	Auxiliary RS232 Interface	38
3.7	Digital Inputs	39
3.7.1	Presence Sensor Input Connections	40
3.7.2	Input Connections From PLC	41
3.8	Digital Outputs	42
3.8.1	Output Connections Using STS400™ Power	42
3.8.2	Output Connections to External Digital Inputs	43
4	DISPLAY MENUS	44
4.1	Main Menu	45
4.2	View Menus	45
4.2.1	Standard	46
4.2.2	Network State	46
4.2.3	Reading Mask	47
4.2.4	Init Counters	48
4.3	Extended Menu	48
5	READING FEATURES	49
5.1	DOF and FOV Data	49
5.1.1	Passenger Car/Light Truck Solutions	49
5.1.2	Commercial Vehicle Solutions	49
5.1.3	Bottom Reading Solutions	49
5.1.4	Hook Chain (Side) Reading Solutions	50
6	SOFTWARE CONFIGURATION	51
6.1	Default Configuration	51
6.2	Backup & Restore Procedures	52
6.2.1	Using VisiSet™	52
6.2.2	Using CBX500 ATS HMI Interface (Keypad/Display)	53
7	MAINTENANCE	54
7.1	STS400™: What You Can and Cannot Do	54
7.2	Cleaning	54
8	TROUBLESHOOTING	55
8.1	General Guidelines	55
9	TECHNICAL FEATURES	56

REFERENCES

CONVENTIONS

This manual uses the following conventions:

"User" refers to anyone using an STS400™ array.

"Reader" refers to the Matrix 410™ ATS reader mounted on the STS400™ array.

"You" refers to the System Administrator or Technical Support person using this manual to install, configure, operate, maintain or troubleshoot an STS400™ station.

REFERENCE DOCUMENTATION

For further details refer to: the VisiSet™ Help On Line, Matrix Reading Methods, Matrix Host Mode Programming, Matrix SW Parameter Guide, provided as supplementary documentation on the VisiSet™ mini-DVD (downloaded ISO file or mini-DVD accessory).

SUPPORT THROUGH THE WEBSITE

Datalogic provides several services as well as technical support through its website. Log on to **www.datalogic.com** and click on the **Industrial Automation** links for further information:

- **PRODUCTS – FIXED INDUSTRIAL BARCODE READERS**

Select your product from the links on the **Fixed Industrial Barcode Readers** page. The product page describes specific Info, Features, Applications, Models, Accessories, and Downloads including documentation, software drivers, and utility programs.

- **SUPPORT & SERVICES – INDUSTRIAL AUTOMATION**

Several links from the **Industrial Automation** list take you to additional services such as: Service Program which contains Maintenance Agreements and Warranty Extensions; Repair Centers; On-Line RMA Return Material Authorizations; Technical Support through email or phone; Downloads for additional downloads.

PATENTS

See www.patents.datalogic.com for patent list.

This product is covered by one or more of the following patents:

Utility patents: EP0996284B1, EP0999514B1, EP1014292B1, JP4435343B2, JP4571258B2, US6512218, US6616039, US7053954, US8058600, US8289387, US8368000, ZL200780053699.6

COMPLIANCE

For installation, use and maintenance it is not necessary to open the readers.

Only connect Ethernet and dataport connections to a network which has routing only within the plant or building and no routing outside the plant or building.

EMC COMPLIANCE

In order to meet the EMC requirements:

- for CBX connections, connect the pin "Earth" to a good Earth Ground

POWER SUPPLY

ATTENTION: READ THIS INFORMATION BEFORE INSTALLING THE PRODUCT

This product is intended to be installed by Qualified Personnel only.

This product is intended to be connected to a UL Listed power supply which supplies power directly to the product.

LED COMPLIANCE

LED emission according to EN 62471.

CE COMPLIANCE

Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

FCC COMPLIANCE

Modifications or changes to this equipment without the expressed written approval of Datalogic could void the authority to use the equipment.



This device complies with PART 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference which may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.


HANDLING

The STS400™ is designed to be used in an industrial environment and is built to withstand vibration and shock when correctly installed, however it is also a precision product and therefore before and during installation it must be handled correctly to avoid damage.

- avoid that the array is dropped.
- do not fine tune the positioning by striking the array.



- do not weld the array into position which can cause electrostatic, heat or reading window damage.
- do not spray paint near the array which can cause reading window damage.



GENERAL VIEW

STS400™




Figure A - STS400-0x8




Figure B - STS400-1x8




Figure C - STS400-205, STS400-305

① ID-NET™ Master

② ID-NET™ Slaves

③ Mounting Slots (4)

④ Positioning Slot

⑤ Reading Windows

1 INTRODUCTION

1.1 STS400™ - SOLUTION FOR TIRES SORTING

STS400™, which means **S**olution for **T**ires **S**orting, is a solution designed to be easily integrated into a sorting system for reading barcodes on the tires.

STS400-005 Reading Station



Tire Sorting Station

The solution, made up of an array of Matrix 410™ ATS readers has been studied to be a pre-mounted, pre-configured system entirely validated at the factory, in order to be quickly and easily installed by any technician.

The STS400™ provides easy maintenance with a smart solution for fast replacement of any single Matrix 410™ ATS reader.

There are a number of STS400™ models which can be chosen to satisfy all the customer needs in terms of: maximum code resolution, conveyor width and depth of field.


- Multiple Matrix 410™ ATS readers are combined in an array designed to cover a fixed conveyor or belt width at a fixed range of distances
- The readers are part of a Master/Slave high speed ID-NET™ network
- The Master collects the data from the Slaves, handles I/O and communicates with the host
- All external connections take place through the CBX500 ATS-001 connection box
- Two photoelectric sensors are included for triggering the reading phase. Alternatively the reading phase can be controlled by Host commands from the serial, Ethernet IP or Fieldbus interfaces.

1.2 TERMINOLOGY

The manual will refer to some technical terms when explaining how to choose and install the STS400™. The following table will list the most used.

Code Resolution


Code Resolution is the width of the narrowest module (element) in a barcode, usually expressed in millimeters. It is also commonly expressed in mils, (thousandths of an inch).



DOF

DOF stands for **Depth Of Field** and it indicates the range (distance from the reader) where the barcode can be read.

Resolution = Module width



FOV


FOV stands for **Field Of View** and describes the reading area at a given reading distance within the DOF.

Horizontal **FOV** defines the reading width of the STS400™ across the conveyor. Vertical **FOV** defines the reading length of the STS400™ parallel to the conveyor.

The guaranteed reading volume is defined as:

$$FOV_{Hmin} \times FOV_{Vmin} \times DOF$$

on Code 128 codes from the Datalogic Test Chart.



Tire Terminology

Width

It is the widest point from sidewall to sidewall of the tire.

Height


It is the difference from the external to the internal diameter of the tire.

Diameter

It is the internal diameter of the tire which will fit the car wheel rim.

Bead

It is the part of the tire which contacts the car wheel rim. The barcode is usually applied here.



1.3 STS400™ FEASIBILITY REQUIREMENTS

In order to make the best STS400™ solution choice which fits the application needs, some basic information is required.


Highest Application Code Resolution: this data is fundamental for choosing the STS400™ model. This information must be the minimum barcode module among all the barcodes to be read in the application.

STS400™ is supplied for two nominal resolutions:

- **High Resolution**, resolution between 0.25 mm (10 mils) and 0.30 mm (12 mils)
- **Standard Resolution**, resolution lower than or equal to 0.30 mm (12 mils)

Note: If the Resolution is higher than 0.25 mm (smaller module width), please contact your local Datalogic representative.

Maximum Application DOF: this data corresponds to the difference between the maximum width (W_{max}) and the minimum width (W_{min}) among all the tires to be sorted:




This information can be achieved by physically measuring the width of all tires to be sorted, and looking for the two limits.

More easily, this information can be achieved by collecting all the tires size information printed on them. (See par. 1.3.1).

STS400™ satisfies different ranges of DOF according to the code resolution and reading station application type:


STS400™ Model	Reading Station Type	Nominal DOF mm (in)
STS400-00x	Top Reading Station Standard Resolution for Car/Light Truck Tires	250 (9.8)
STS400-01x	Top Reading Station High Resolution for Car/Light Truck Tires	200 (7.9)
STS400-10x	Top Reading Station Standard Resolution for Commercial Vehicle Tires	400 (15.7)
STS400-11x	Top Reading Station High Resolution for Commercial Vehicle Tires	380 (15.0)
STS400-20x	Bottom Reading Station	140 (5.5)
STS400-30x	Hook Chain (Side) Reading Station	155 (6.1)

Conveyor Operating Width: This is the effective operative width where the tires can run:



Maximum Application FOV: This data is the maximum reading width where a barcode can be found by the STS400™.

Because the barcode is located on or next to the Bead of the tire, the barcode will never be found at the edges of the Conveyor Operating Width. The Maximum Application FOV therefore can always be less than the Conveyor Operating Width:



The figure above shows a sectional view of the tires in order to better understand the difference between the Maximum Application FOV and the Conveyor Operating Width.

The Maximum Application FOV can be calculated with the following formula:

$$\text{FOV} = \text{Operating Width} - 2 * (\text{Minimum Tire Height} - \text{Barcode Position Margin})$$

The Barcode Position Margin takes into account the distance from the Bead where the barcode could be applied.

Maximum Conveyor Speed: The STS400™ with factory default configuration can support speeds up to 1 m/s (196.85 fpm, 60 m/min).



NOTE: Higher speeds can be obtained by modifying the configuration, please contact your local Datalogic representative for feasibility.


1.3.1 Extracting Tire Size From Tire Sidewall Markings

The best way to find out your tire size is to actually look at the tire sidewall. As you can see in the figure below, there is generally a lot of different information on the tire; however, for our purpose, we just need 3 pieces of information:

1. **Tire Width:** the “215” designation states the Width of the tire in millimeters at the widest point from sidewall to sidewall when mounted on the correct wheel.
2. **Tire Height:** the “65” designation is the Aspect Ratio. This ratio is calculated by dividing the section Height by the Width. Therefore the tire height is calculated as:

Height = Ratio * Width / 100

3. **Tire Diameter:** the “15” designation is the Diameter of the wheel rim in inches. This is the exact size that the tire will fit.



Once the whole list of the nominal values of all the tires has been collected, it is very easy to understand the application needs, and chose the correct STS400™ model. See the following sample table:

	W [mm]	R [%]	D [Inch]	H [mm]	Dint [mm]	Dext [mm]
Tire 1	120	70	12	84	304.8	472.8
Tire 2	175	65	14	114	355.6	583.1
Tire 3	185	55	14	102	355.6	559.1
Tire 4	205	60	15	123	381.0	627.0
Tire 5	205	65	15	133	381.0	647.5
Tire 6	190	50	17	95	431.8	621.8
Tire 7	100	100	18	100	457.2	657.2
Tire 8	275	45	18	124	457.2	704.7
Tire 9	275	45	20	124	508.0	755.5
Minimum [mm]	100.0			84.0		
Maximum [mm]	275.0			133.3	508.0	755.5
DOF Required [mm]	175.0					


Note: Dext is the external tire diameter. Even if this data is not used for the best choice of the STS400™, the above table shows it. It can be calculated as: $D_{ext} = D_{int} + (2 * H)$.

1.4 STS400™ MODEL DESCRIPTIONS

Once the main specifications have been collected, it's possible to choose the STS400™ model which best fits the application according to the following rules:

- Highest Application Code Resolution $\leq$ STS400™ Nominal Code Resolution
- Maximum Application DOF $\leq$ STS400™ Nominal DOF
- Maximum Application FOV $\leq$ STS400™ Nominal Horizontal FOV

The models differ by Application Type, Code Resolution, and number of readers.



Single Matrix 410™ ATS-xxx models are used as stand alone readers having the same characteristics as the relative application type STS400™ models. They are also used as replacement readers for the relative STS400™ stations.

The Reading Features of the various STS400™ models are given in chapter 5.

1.5 POWER REQUIREMENTS

The STS400™ solution kit doesn't include a power supply unit, which has to be ordered separately. The maximum power required depends on the model.

Power is supplied to the system through its connection box CBX500 ATS. In the case of STS400-10x models, in addition to system power through the CBX500 ATS, the illuminator is supplied directly through the QL100 connectors.

The following table indicates the compatible power supply to use according to the STS400™ model. The supply current consumption values are given considering the default parameter settings with the array working at maximum throughput.

Model	DC Supply Current Max @ 24 V $\pm$ 10%	Peak Supply Current Max @ 24 V $\pm$ 10%
Suggested Power Supply: PWR-120 or PG-120-K0x		
Bottom Reading Solution		
STS400-205	1.03 A	5.4 A for 2.8 ms
STS400-206	1.23 A	5.4 A for 2.8 ms
Hook Chain (Side) Reading Solution		
STS400-305	1.06 A	5.4 A for 3.1 ms
STS400-306	1.27 A	5.4 A for 3.1 ms
Suggested Power Supply: PWR-480B		
Top Reading Passenger Car/Light Truck Solution		
STS400-0x4	0.9 A	3.6 A for 3.5 ms
STS400-0x5	1.13 A	5.4 A for 3.5 ms
STS400-0x6	1.35 A	5.4 A for 3.5 ms
STS400-0x7	1.58 A	7.2 A for 3.5 ms
STS400-0x8	1.80 A	7.2 A for 3.5 ms
Suggested Power Supply: PWR-480B		
Top Reading Commercial Vehicle Solution		
STS400-1x5	1.43 A	16.2 A for 3.5 ms
STS400-1x6	1.71 A	16.2 A for 3.5 ms
STS400-1x7	2.00 A	21.6 A for 3.5 ms
STS400-1x8	2.28 A	21.6 A for 3.5 ms

1.6 STS400™ ACCESSORIES

Accessory	Description	Order No.
Power Supplies		
PG-120-K01	AC/DC Power Supply Kit (EU)	93ACC0046
PG-120-K02	AC/DC Power Supply Kit (UK)	93ACC0047
PG-120-K03	AC/DC Power Supply Kit (US)	93ACC0048
PWR-120	POWER UNIT 110/230VAC 24V 120 W	93ACC1530
PWR-480B	POWER UNIT 110/230VAC 24V 480 W	93ACC0076
Host Interface Modules		
BM200/BM210	Ethernet TCP/IP Module STD/IP65 for CBX500	93ACC1851, 93ACC1852
BM300/BM310	Profibus Module STD/IP65 for CBX500	93ACC1810, 93ACC1811
BM400	DeviceNet Module IP65 for CBX500	93ACC1814
BM500/BM510/BM520	Ethernet/IP Module STD/IP65/IP54 for CBX500	93ACC1812, 93ACC1813, 93ACC1840
BM600	CAN Open Module for CBX500	93ACC1815
BM700/BM710	Profinet IO Module STD/IP65 for CBX500	93ACC1816, 93ACC1886
BM1100	CC-Link Module for CBX500	93ACC1845
BM1200/BM1210	Modbus TCP Module STD/IP65 for CBX500	93ACC1848, 93ACC1849
Software Management		
Datalogic WebSentinel-IMAGES 005	System Supervisor (up to 5 arrays)	93A100027
Datalogic WebSentinel-IMAGES 064	System Supervisor (up to 64 arrays)	93A100028
Datalogic WebSentinel-IMAGES 256	System Supervisor (up to 256 arrays)	93A100029

2 INSTALLATION


2.1 STS400™ SUPPORTING FRAME

STS400™ has been optimized to be mounted on aluminum profiles. A frame made up of aluminum profiles allows the easiest and fastest mounting, and in most cases is the best choice.

However, STS400™ can also be mounted on different supports like a fixed column.

Because it is impossible to supply a standard frame which fits all the infinite needs of the customers, it must be designed during the feasibility study of the specific application.

When studying a frame, it is suggested to design it with some safe margins for adjustment because of unforeseen changes at installation time like obstacles or different height requirements. Even if the STS400™ height can be calculated in advance, it is suggested to leave freedom on all three axes for fine adjustment in the field. The following figure shows how this can be achieved and is the type suggested by Datalogic.



In this sample frame the STS400™ can be moved up-down, backward-forward, and left-right:


The length of the aluminum profiles has to be dimensioned according to the following constraints:

- physical conveyor width
- conveyor height from floor to the tire reading plane
- Application DOF
- STS400™ model
- minimum width (W_{min}) of the tires

The next three paragraphs suggest the formulas to be used for the frame dimensioning.

2.1.1 Frame Width

The frame Width has to be calculated according to the distances shown in the following figure:



The **Safe** clearance between the frame and the conveyor sides has to be chosen according to the **Maximum Side Room** available. It is suggested to always keep at least of 200 mm of **Safe** clearance.

The length of the frame profiles W can be calculated in 2 ways, according to whether the STS400™ main plate is wider than the conveyor **Conveyor Width** or not:


If Conveyor Width > STS Main Plate then: **$W = \text{Conveyor Width} + (2 * \text{Safe Margin})$**

If Conveyor Width ≤ STS Main Plate then: **$W = \text{STS Main Plate} + (2 * \text{Safe Margin})$**

Note: The STS400-xx7 models require a 70 or 55 mm shift to center the FOV over the conveyor and therefore must be accounted for in the frame width calculation.

2.1.2 Frame Length


It is suggested to keep at least 500 mm of **Safe** clearance for the frame Length (L). This allows good frame stability and freedom for moving both the reading phase sensor(s) and the STS400™, forward or backward:




Note: There is not a specific calculation for (L).

2.1.3 Frame Height

This is the dimension most influenced by the STS400™ model. The frame profile, indicated as Height (H), is calculated according to the distances shown in the following figure:



The STS400™ Maximum Reading distance is considered starting from the reader window surface to the maximum reading point:



This distance changes according to the STS400™ model:


STS400™ Model	Reading Station Type	Maximum Reading Distance mm (in)
STS400-00x	Top Reading Station Standard Resolution for Car/Light Truck Tires	1140 (44.9)
STS400-01x	Top Reading Station High Resolution for Car/Light Truck Tires	910 (35.8)
STS400-10x	Top Reading Station Standard Resolution for Commercial Vehicle Tires	1280 (50.4)
STS400-11x	Top Reading Station High Resolution for Commercial Vehicle Tires	1310 (51.6)
STS400-20x	Bottom Reading Station	457 (18)
STS400-30x	Hook Chain (Side) Reading Station	560 (20)

Finally the frame Height (H) can be calculated by the following formula:

$$H = \text{Conveyor Height} + \text{Wmin} + \text{Max Reading Distance} + \text{STS400 Width} + \text{Safe Length} - \text{Foot}$$

Where:

- **Safe Length** is an extra length of 50 to 100 mm on the top of the frame, used for fine adjustment at installation time (if needed);
- **Foot** is usually considered to be roughly 50 mm:



2.1.4 Frame Bill Of Materials


We suggest using Bosch aluminum profiles; although any other brand can fully satisfy this purpose.

The 45 x 45 mm profile section is the best compromise between frame stability and price.

The following bill of materials indicates a list of generic profiles: W, L and H.

Description	Quantity
Profile W	3
Profile L	6
Profile H	4
Angular brackets	20


Note: It is suggested to double the angular brackets on both the ends of the profile supporting the STS400™:




Once the frame has been fully mounted, the STS400™ can be mechanically mounted.

2.2 MECHANICAL DIMENSIONS


STS400-004




STS400-005, STS400-205, STS400-305




STS400-015




STS400-105




STS400-115




STS400-006, STS400-206, STS400-306




STS400-016




STS400-106




STS400-116




STS400-007




STS400-017




STS400-107




STS400-117




STS400-008




STS400-018



STS400-108




STS400-118




2.3 MOUNTING DISTANCE (DOF)


2.3.1 STS400-004, STS400-005, STS400-006, STS400-007, STS400-008




2.3.2 STS400-015, STS400-016, STS400-017, STS400-018




2.3.3 STS400-105, STS400-106, STS400-107, STS400-108




2.3.4 STS400-115, STS400-116, STS400-117, STS400-118



2.3.5 STS400-205, STS400-206



2.3.6 STS400-305, STS400-306




2.4 SUPPORTING PROFILE HEIGHT ADJUSTMENT

The frame profile supporting the STS400™ must be positioned at the correct height in order to completely overlap the STS400™ nominal DOF to the application DOF.

Note: The application DOF is the difference between the maximum tire width and the minimum tire width.

If the DOF required by the application is less than the STS400™ nominal DOF, it's strongly suggested to balance the overlap by keeping the centers of both DOFs coincident:



In the figure on the right, the STS400™ nominal DOF is perfectly overlapped and centered on the application DOF.

The installation height (**Inst H** in the figure), which is the distance from the reader window surface to the conveyor plane is calculated by the following formula:

$$\text{Inst H} = \text{Tire_W}_{\min} + (\text{Application_DOF} / 2) + \text{DOFc_dist}$$

Where the **DOFc_dist** is the distance between the reader window surface and the center of the STS400™ DOF; this value changes according to the model:

STS400™ Model	Reading Station Type	Maximum Reading Distance mm (in)
STS400-00x	Top Reading Station Standard Resolution for Car/Light Truck Tires	1015 (40)
STS400-01x	Top Reading Station High Resolution for Car/Light Truck Tires	810 (31.9)
STS400-10x	Top Reading Station Standard Resolution for Commercial Vehicle Tires	1080 (42.5)
STS400-11x	Top Reading Station High Resolution for Commercial Vehicle Tires	1120 (44.1)
STS400-20x	Bottom Reading Station	*
STS400-30x	Hook Chain (Side) Reading Station	482.5 (19)

* For Bottom reading stations the reading distance is a fixed value approximately equal to the top of the conveyor plane. **Tire_W_{min}** is not significant, **Application_DOFF/2** is negligible. **Inst H** is typically set to the minimum reading distance, see par. 2.3.4.

2.5 STS400™ MAIN PLATE MOUNTING

Once the supporting profile has been positioned at the correct height we can proceed with the STS400™ mechanical mounting.

STS400™ has been designed to be easily installed by one person using the T-bolt, special plate supporting nut and locknut supplied in the kit:




Figure 1- STS400™ Plate Supporting Nut

The plate supporting nut has to be coupled to the frame with the M8 x 25 mm T-bolt:





Figure 2- STS400™ Plate Support Assembly


Mount the plate support assembly onto the bottom side of the STS400™ supporting frame. When the T-bolt is inserted into the profile slot, position it directly over the center¹ of the operating width and completely tighten the nut:




¹ For STS400™ models having an even number of readers, the main plate slot, FOV and operating width are congruent. If the STS400™ model has an odd number of readers then an offset must be applied from the center of the operating width. See par. 2.5.1 for details.

Finally the STS400™ can be mounted onto the station frame.

The STS400™ has to be installed onto the station frame in the conveyor direction so that the main plate slot (reader side) is aligned with the plate support assembly.




Slide the main plate slot between the plate support assembly and the supporting profile until it reaches the end.



The plate support assembly can fully support the STS400™ weight without human help.

Fix the STS400™ using 4 T-bolts and nuts (not supplied) to the supporting profile. When the main plate slot is fully inserted onto the plate support assembly, the 4 mounting slots are aligned with the supporting profile groove:




Also screw the locknut onto the plate support assembly and tighten it.

2.5.1 STS400™ Plate Support Assembly Positioning for Odd Number of Readers

The STS400™ kits having an odd number of Matrix 410™ ATS readers are the -xx5 or -xx7 models.

When mounting one of these models the plate support assembly can't be fixed exactly over the center of the operating width because the main plate slot no longer corresponds to the center of the FOV. A positional offset must be applied to center the FOV over the operating width.


The following figure shows what happens when the plate support assembly is centered over the operating width with an STS400™ model having an odd number of readers:



STS400-xx7 centered over conveyor

It's clear that the plate support assembly must have a positional offset from the center.

Looking at the frame from the Output Side (tires coming out of the page), in order to align the center of the FOV with the center of the conveyor, an offset towards the left side has to be applied:



STS400-xx7 with offset over conveyor

The positional offset from the operating width center changes according to the STS400™ model used:


STS400™ Model	Reading Station Type	Direction	Offset mm (in)
STS400-x15	High Resolution	➔	55 (2.17)
STS400-x17	High Resolution	➔	55 (2.17)
STS400-x05	Standard Resolution	➔	70 (2.76)
STS400-x07	Standard Resolution	➔	70 (2.76)

2.6 PRESENCE SENSOR POSITIONING

The STS400™ system comes with a pair of photocells that can be used to detect the presence of the tire on the conveyor and trigger the beginning and the end of the reading phase. When used, they must be positioned and mounted at the conveyor belt level depending on the size of the tires that must be handled.

Position the presence sensors according to the following procedure:

1. Retrieve the size of the minimum tire height (H_{min}) and the minimum tire width (W_{min}) of the tires.
2. Determine the field of view along the conveyor direction (FOV_v) at the maximum distance. See the table below.
3. If the minimum tire height (H_{min}) is less than the $FOV_v/2$ at the maximum distance, then both Reading Phase ON and Reading Phase OFF presence sensors are required and they must be mounted at the H_{min} distance from the edges of the vertical FOV as shown in the figure below:




Top Reading Station with Two Presence Sensors

STS400™ Model	Reading Station Type	Vertical FOV @ Maximum Reading Distance mm (in)
STS400-00x	Top Reading Station Standard Resolution for Car/Light Truck Tires	240 (9.5)
STS400-01x	Top Reading Station High Resolution for Car/Light Truck Tires	190 (7.5)
STS400-10x	Top Reading Station Standard Resolution for Commercial Vehicle Tires	270 (10.6)
STS400-11x	Top Reading Station High Resolution for Commercial Vehicle Tires	200 (7.9)
STS400-20x	Bottom Reading Station	* see note
STS400-30x	Hook Chain (Side) Reading Station	159 (6.3)

In some cases the system can work with only one photocell.


If the minimum tire height (H_{min}) is greater than the $FOV_v/2$ at the maximum distance, then only a single presence sensor is required and it must be mounted at the mid point of the field of view as shown in the figure below:



NOTE: This configuration requires modifying the Master default Reading Phase OFF parameter to External Trigger Trailing Edge, Complete Read.

H_{min} = minimum tire height (lowest profile tire)

PS1 = Reading Phase ON/OFF Photocell



Bottom Reading Station with Single Presence Sensor



NOTE: For Bottom Reading Stations installed at the minimum nominal DOF of 317 mm (12.5 in), the Vertical FOV is 145 mm (5.7 in). If allowed by the application, it is suggested to use this value for the conveyor gap in order to maximize the reading area.

Smaller gaps can be used and maximized by modifying the configuration, please contact your local Datalogic representative for feasibility.

3 ELECTRICAL CONNECTIONS

3.1 STS400™ WIRING DIAGRAM




Figure 3 - STS400™ Array Wiring




Figure 4 - STS400-1xx Additional Wiring

See par. 3.3.1 for wiring illuminator power on STS400-1xx models.

3.2 CBX CONNECTION BOX PINOUT

The STS400™s all connect to the CBX500 ATS-001 as shown in the previous diagram. The table below gives the pinout of the CBX terminal block connectors.

CBX500 ATS Terminal Block Connectors			
Input Power			
Vdc	Power Supply Input Voltage +		
GND	Power Supply Input Voltage -		
Earth	Protection Earth Ground		
Inputs			
+V	Power Source – External Trigger		
I1A	External Trigger A (polarity insensitive)		
I1B	External Trigger B (polarity insensitive)		
-V	Power Reference – External Trigger		
+V	Power Source – Inputs		
I2A	Input 2 A (polarity insensitive)		
I2B	Input 2 B (polarity insensitive)		
-V	Power Reference – Inputs		
Outputs			
+V	Power Source - Outputs		
-V	Power Reference - Outputs		
O1+	Output 1 +		
O1-	Output 1 -		
O2+	Output 2 +		
O2-	Output 2 -		
Auxiliary Interface			
TX	Auxiliary Interface TX		
RX	Auxiliary Interface RX		
SGND	Auxiliary Interface Reference		
ID-NET™			
REF	Network Reference		
ID+	ID-NET™ network +		
ID-	ID-NET™ network -		
Shield	Network Cable Shield		
Main Interface			
	RS232	RS485 Full-Duplex	
	TX	TX+	
	RX	*RX+	
	RTS	TX-	
	CTS	*RX-	
	SGND	SGND	

* Do not leave floating, see par. 3.5.2 for connection details.



NOTE: To avoid electromagnetic interference when the reader is connected to a CBX connection box, verify the jumper positions in the CBX as indicated in its Installation Manual.

3.3 POWER SUPPLY

Power is supplied through the CBX500 ATS spring clamp terminal pins as shown in Figure 5:




Figure 5 - Power Supply Connections

For all STS400™ models the power must be 24 Vdc only. See par. 1.5 for recommended power supplies.

It is recommended to connect the array CHASSIS to earth ground (Earth) by setting the appropriate jumper in the CBX connection box. See the CBX Installation Manual for details.

3.3.1 STS400-1xx Models

For STS400-1xx models, in addition to powering the system through the CBX500 ATS, power the illuminators using the CAB-MLP-05 cable connected directly between the first QL100 and the 24 Vdc power source. Connect the **White wire to Vdc** and **Blue wire to GND**. Connect the cable shield to Earth ground.

3.4 M12-D 4-PIN CONNECTOR (ETHERNET)

An M12 D-Coded connector is provided for the on-board Ethernet connection. This interface is IEEE 802.3 10 BaseT and IEEE 802.3u 100 BaseTx compliant.




Figure 6 - M12 D-Coded Female Ethernet Network Connector

M12 D-Coded Ethernet Network Connector pinout		
Pin	Name	Function
1	TX +	Transmitted data (+)
2	RX +	Received data (+)
3	TX -	Transmitted data (-)
4	RX -	Received data (-)

3.5 MAIN SERIAL INTERFACE



CAUTION: Do not connect to the Main Interface spring clamp terminals if using Host Interface Modules (Fieldbus) with the CBX500.

The signals relative to the following serial interface types are available on the CBX spring clamp terminal blocks.

The main serial interface type and its parameters (baud rate, data bits, etc.) can be defined by the user via VisiSet™ software. For more details refer to the "Communication" folder in the VisiSet™ Help On Line.

Details regarding the connections and use of the interfaces are given in the next paragraphs.

3.5.1 RS232 Interface

The RS232 interface can be used for Point-to-Point connections. When it is connected to the host computer it allows both transmission of code data and reader configuration by VisiSet™.

The following pins are used for RS232 interface connection:

CBX500 ATS	Function
TX	Transmit Data
RX	Receive Data
RTS	Request To Send
CTS	Clear To Send
SGND	Signal Ground

It is always advisable to use shielded cables. The overall maximum cable length must be less than 15 m (49.2 ft).




Figure 7 – RS232 Main Interface Connections Using Hardware Handshaking

The RTS and CTS signals control data transmission and synchronize the connected devices.




Figure 8 - RS232 Control Signals

If the RTS/CTS handshaking protocol is enabled, the Matrix 410™ activates the RTS output to indicate a message is to be transmitted. The receiving unit activates the CTS input to enable the transmission.

3.5.2 RS485 Full-Duplex Interface

The RS485 full-duplex (5 wires + shield) interface is used for non-pollled communication protocols in point-to-point connections over longer distances (max 1200 m / 3940 ft) than those acceptable for RS232 communications or in electrically noisy environments.

The CBX pinout follows:

CBX500 ATS	Function
TX+	RS485 Transmit Data +
RX+	RS485 Receive Data +
TX-	RS485 Transmit Data -
RX-	RS485 Receive Data -
SGND	Signal Ground




Figure 9 - RS485 Full-duplex Connections



NOTE: For applications that do not use RX485 signals, do not leave these lines floating but connect them to SGND as shown below.




Figure 10 - RS485 Full-duplex Connections using Only TX Signals

3.6 AUXILIARY RS232 INTERFACE

The RS232 auxiliary interface is available for Point-to-Point connections. When it is connected to the host computer it allows both transmission of code data and reader configuration by VisiSet™.

The parameters relative to the aux interface (baud rate, data bits, etc.) as well as particular communication modes such as LOCAL ECHO can be defined through the Communication folder of the VisiSet™ utility program.

The 9-pin female Auxiliary Interface connector inside the CBX is the preferred connector for device configuration or communication monitoring.




Figure 11 - 9-pin female connector

If permanent system wiring is required, the following pins are used to connect the RS232 auxiliary interface:

CBX500 ATS	Function
RX	Auxiliary Interface Receive Data
TX	Auxiliary Interface Transmit Data
SGND	Auxiliary Interface Reference




Figure 12 - RS232 Auxiliary Interface Connections



NOTE: Do not connect the Aux Interface to the CBX spring clamp connectors and the 9-pin connector simultaneously.

3.7 DIGITAL INPUTS

There are two optocoupled polarity insensitive inputs available on the reader: Input 1 (External Trigger) and Input 2, a generic input:

These inputs can be used to control (start/stop) the reading phase:

Source \ Parameter	Reading Phase ON Input	Reading Phase OFF Input
Single Presence Sensor	External Trigger Leading Edge	External Trigger Trailing Edge
Two Presence Sensors	External Trigger Leading Edge	Input 2 Leading Edge
PLC Digital Output	External Trigger Leading Edge or Input 2 Leading Edge	External Trigger Trailing Edge or Input 2 Trailing Edge



NOTE: Alternatively, host communication output commands (Serial or Fieldbus) can be used to control the reading phase. See the Configuration Parameters Help On Line for details.

The electrical features of both inputs are:

$$V_{AB} = 30 \text{ Vdc max.}$$

$$I_{IN} = 10 \text{ mA (reader)} + 12 \text{ mA (CBX) max.}$$

The active state of these inputs is selected in software. Refer to the VisiSet™ Help On Line.

An anti-disturbance filter is implemented in software on both inputs so that the minimum pulse duration is $\cong 0.5$ milliseconds. This value can be increased through the software parameter Debounce Filter, see the Digital I/O folder in the VisiSet™ Help On Line for further details.

These inputs are optocoupled and can be driven by PNP type commands.



NOTE: Polarity insensitive inputs assure full functionality even if pins A and B are exchanged.

3.7.1 Presence Sensor Input Connections



CAUTION: Power is available directly to the Input Device, independently from the Power Supply Switch inside the CBX.

The sensors included in the STS400™ have a standard pinout (brown = +Vdc; blue = GND; black = switched) and can be connected to the Trigger and Input 2 as shown in the figures below.

Sensor 1	CBX500 ATS Row 2	Function
brown	+V	Power Source - External Trigger
black	I1A	External Trigger A (polarity insensitive)
blue	I1B	External Trigger B (polarity insensitive)
	-V (bridge to I1B)	Power Reference - External Trigger




Figure 13 – Presence Sensor Connected to External Trigger

The yellow Trigger LED on the reader is on when the active state of the External Trigger corresponds to ON.

Sensor 2	CBX500 ATS Row 3	Function
brown	+V	Power Source - Inputs
black	I2A	Input 2 A (polarity insensitive)
blue	I2B	Input 2 B (polarity insensitive)
	-V (bridge to I2B)	Power Reference - Inputs




Figure 14 – Presence Sensor Connected to Input 2

3.7.2 Input Connections From PLC

Alternatively, the reading system can be controlled by a digital output of a PLC. For this purpose, connect the switched signal and the appropriate reference level as shown in the figures below.

PLC Signal	CBX500 ATS Row 2	Function
Input	I1A	External Trigger A (polarity insensitive)
Reference	I1B	External Trigger B (polarity insensitive)




Figure 15 - External Trigger Connected to PLC

The yellow Trigger LED on the reader is on when the active state of the External Trigger corresponds to ON.

PLC Signal	CBX500 ATS Row 3	Function
Input	I2A	Input 2 A (polarity insensitive)
Reference	I2B	Input 2 B (polarity insensitive)




Figure 16 - Input 2 Connected to PLC

3.8 DIGITAL OUTPUTS

Two optocoupled general purpose outputs are available. The meaning of the two outputs Output 1 and Output 2 can be defined by the user. They are typically used to signal the data collection result. They are also available to the Host (either serial or Fieldbus) to be driven independently.

The electrical features of the two outputs are the following:

$$V_{CE} = 30 \text{ Vdc max.}$$

$$I_{CE} = 40 \text{ mA continuous max.; } 130 \text{ mA pulsed max.}$$

$$V_{CE \text{ saturation}} = 1 \text{ Vdc max. @ } 10 \text{ mA}$$

$$P_D = 80 \text{ mW Max. @ } 45^\circ \text{C ambient temp.}$$

By default, Output 1 is associated with the Partial Read and No Read events, which activates when the code(s) signaled by the external trigger are not decoded, and Output 2 is associated with the Complete Read event, which activates when all the selected codes are correctly decoded.

The output signals are fully programmable being determined by the configured Activation/Deactivation events, Deactivation Timeout or a combination of the two. Refer to the Digital I/O folder in the VisiSet™ Help On Line for further details.

3.8.1 Output Connections Using STS400™ Power



CAUTION: Power is available directly to the Output Device, independently from the Power Supply Switch inside the CBX.

The digital outputs can power and drive small devices meeting the electrical characteristics above such as electronic switches which can then manage larger power consuming devices such as signaling lights or other machinery.

CBX500 ATS	Function
+V	Power Source - Outputs
O1+	Output 1 +
O1-	Output 1 -
O2+	Output 2 +
O2-	Output 2 -
-V	Power Reference Outputs




Figure 17 - Open Emitter Output Using STS400™ Power




Figure 18 - Open Collector Output Using STS400™ Power

3.8.2 Output Connections to External Digital Inputs

Alternatively, the reading system's digital outputs can be used to control a digital input of another device such as a PLC. For this purpose, connect the switched signal and the appropriate reference level as shown in the figures below.

CBX500 ATS	Function
O1+	Output 1 +
O1-	Output 1 -
O2+	Output 2 +
O2-	Output 2 -




Figure 19 - Output Connected to External Digital NPN Input




Figure 20 - Output Connected to External Digital PNP Input

4 DISPLAY MENUS



NOTE: While working on the display the complete reading station is offline. The Offline state means that no readings are performed, no data is transmitted to the PLC and any connection to WebSentinel will be lost. The display menus allow you to: change the messages on the display (View), perform backup and restore, and reset the counters.

If the reading station is turned on and the system is ready, the master-reader shows the most important values on the display.

```
Matrix 410 ATS-XXX
6.xx          SYN M00
SN XXXXXXXXXX
ETH XXX.XXX.XXX.XXX
```

The display can be used with the three buttons below it. The up arrow button allows you to scroll up through the menu. The down arrow button allows you to scroll down through the menu. With the middle button, you can confirm your selection.



To access the menus, press the two outermost buttons simultaneously for several seconds.

4.1 MAIN MENU

To enter the Menu press the **Up** and **Down** buttons simultaneously. The menu structure is shown below.

Menu: **[Exit]** (exits HMI Interface menu)

Test Mode

Focus/Locate

Calibration

Code Setting

View

Extended (enters Extended menu)

Extended: **[Exit]** (returns to Main menu)

Backup

Yes (performs Backup - uninterruptible)

No (returns to Extended menu)

Restore

Yes (performs Restore - uninterruptible)

No (returns to Extended menu)

To move through the list press and release the **Up** or **Down** key.

To select an item or enter a submenu, press and release the **Enter** key. After executing an HMI function the display shows a result message and then automatically exits from the menu structure.

To exit a menu, press and release the **Enter** key at the **[Exit]** item.

To exit from a running HMI function, press and release the **Enter** key. These functions will also exit upon their configured timeout.

4.2 VIEW MENUS



NOTE: This menu item is only visible if the connected reader is set as master.

Using this menu item, you can select between different views to be shown on the display.

4.2.1 Standard

In this standard view the following content will be shown on the display:

Row 1: Reading Result

Rows 2 and 3: Code Content

Row 4: Number of digits in code and Angle of code in image

Good Read	Good 1234567890 0010 Dgt 351 Deg
No Read	No Read
Reading Active	Reading ...

4.2.2 Network State

In this view the state of the slave readers, connected to the ID-NET™ network, can be checked. Below the address number the status of the reader is displayed as a symbol.

No Error	1 Network 15 *****----- 16 Network 31 -----
Slave 2 missing	1 Network 15 *?***----- 16 Network 31 -----

* = Reader with no error

! = Reader with an error

? = Reader missing in ID-NET network

4.2.3 Reading Mask

In VisiSet™, if the Array Layout Monitor parameter in the Display folder is enabled, it changes the appearance of the reading mask.

Array Layout Monitor Enabled

If the Array Layout Monitor parameter is enabled, on row one, the display shows the result of the reading phase: code content, or read event message.

Row two shows the reading phase counter and read rate counting from the last restart of the system. These values are reset if the reader configuration is changed or a manual reset of the statistics is performed (Init Counters).

On row three, the reading mask for the master and slave readers (ordered from left to right) is shown with the numbers 0 and 1. A successful read is presented as a 1 for the readers who have read the code.

The network state on row four has the same meaning as in par. 4.2.2.

Row 1: Last Reading Result

Row 2: Reading Phase Count and Statistics

Row 3: Reading Mask

Row 4: Network State

Good Read Master and Slave 1	<pre> 1234567890 P=0000001 GR=100.00% 1100000000000000 *****----- </pre>
Good Read Slave 3 and Slave 4	<pre> 1234567890 P=0000001 GR=100.00% 0001100000000000 *****----- </pre>
No Read	<pre> No Read P=0000002 GR=50.00% 0000000000000000 *****----- </pre>

Array Layout Monitor Disabled

If the Array Layout Monitor parameter is disabled, on row one, the display shows the result of the reading phase: code content, or read event message.

Row two shows the reading statistics based on the last 100 reading phases: **Good Read**, **No Read**, **Multiple Read** (more codes read than expected) and **Partial Read** (less codes read than expected). The percentages range from 00 to 99.

On row three (and four which is not used for STS400™), the reading mask for the master and slave readers (ordered from left to right) is shown with the numbers 0 and 1. A successful read is presented as a 1 for the readers who have read the code.

Row 1: Last Reading Result
 Row 2: Statistics
 Rows 3 and 4: Reading Mask

Good Read Master and Slave 1	1234567890 G99% N01% M00% P00% 1100000000000000 0000000000000000
Good Read Slave 3 and Slave 4	1234567890 G99% N01% M00% P00% 0001100000000000 0000000000000000
No Read	No Read G99% N01% M00% P00% 0000000000000000 0000000000000000

4.2.4 Init Counters



NOTE: This menu item is only visible if the connected reader is set as master and the Array Layout Monitor parameter is enabled.

Use the following procedure to reset the Reading Mask statistics to 0:

1. Enter the Menu (by pressing the two arrow buttons simultaneously)
2. Select the "View" item with the arrow buttons and confirm with the middle button.
3. Select the "Init Counters" item with the arrow buttons and confirm with the middle button.

4.3 EXTENDED MENU

Through this menu item the parameters and calibrations of the complete system will be backed up or restored in the BM100 backup module inside the CBX500 ATS-001.

To perform this procedure, see par. 6.2.2.

5 READING FEATURES

5.1 DOF AND FOV DATA

5.1.1 Passenger Car/Light Truck Solutions

PN	Description	Readers	Code Resolution	Focus Distance	Min Reading Distance	Max Reading Distance	Vertical FOV @ min distance	Horizontal FOV @ min distance
		qty	mm (mils)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)
937401075	STS400-004	4	0.30 (12)	1065 (41.9)	890 (35)	1140 (44.9)	184 (7.2)	665 (26.2)
937401023	STS400-005	5						805 (31.7)
937401024	STS400-006	6						945 (37.2)
937401025	STS400-007	7						1085 (42.7)
937401026	STS400-008	8						1225 (48.2)
937401027	STS400-015	5	0.25 (10)	788 (31)	710 (28)	910 (35.8)	146 (5.7)	635 (25)
937401028	STS400-016	6						745 (29.3)
937401029	STS400-017	7						855 (33.7)
937401030	STS400-018	8						965 (38)

5.1.2 Commercial Vehicle Solutions

PN	Description	Readers	Code Resolution	Focus Distance	Min Reading Distance	Max Reading Distance	Vertical FOV @ min distance	Horizontal FOV @ min distance
		qty	mm (mils)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)
937401037	STS400-105	5	0.35 (14)	1065 (41.9)	880 (34.6)	1280 (50.4)	184 (7.2)	805 (31.7)
937401038	STS400-106	6						945 (37.2)
937401039	STS400-107	7						1085 (42.7)
937401040	STS400-108	8						1225 (48.2)
937401085	STS400-115	5	0.25 (10)	1080 (42.5)	930 (36.6)	1310 (51.6)	143 (5.7)	625 (24.6)
937401086	STS400-116	6						735 (28.9)
937401087	STS400-117	7						845 (33.3)
937401088	STS400-118	8						955 (37.6)

5.1.3 Bottom Reading Solutions

PN	Description	Readers	Code Resolution	Focus Distance	Min Reading Distance	Max Reading Distance	Vertical FOV @ min distance	Horizontal FOV @ min distance
		qty	mm (mils)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)
937400018	STS400-205	5	0.30	380	317	457	145	754 (29.7)
937400019	STS400-206	6	(12)	(15)	(12.5)	(18)	(5.7)	894 (35.2)

DOF = Max Reading Distance - Min Reading Distance

Guaranteed Reading Volume = $FOV_{Hmin} \times FOV_{Vmin} \times DOF$ on Code 128 codes from the Datalogic Test Chart

5.1.4 Hook Chain (Side) Reading Solutions

PN	Description	Readers	Code Resolution	Focus Distance	Min Reading Distance	Max Reading Distance	Vertical FOV @ min distance	Horizontal FOV @ min distance
		qty	mm (mils)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)
937400020	STS400-305	5	0.30	483	405	560	141	748 (29.4)
937400021	STS400-306	6	(12)	(19)	(15.9)	(22)	(5.6)	888 (35)

DOF = Max Reading Distance - Min Reading Distance

Guaranteed Reading Volume = $FOV_{Hmin} \times FOV_{Vmin} \times DOF$ on Code 128 codes from the Datalogic Test Chart

6 SOFTWARE CONFIGURATION

6.1 DEFAULT CONFIGURATION

The factory default configuration for the STS400™ is given here for reference:

MASTER READER CONFIGURATION

The following gives an excerpt of the relevant configuration parameters

→ READING SYSTEM LAYOUT:

- Device Network Setting = Alone o ID-NET
- Topology Role = Master (synchronized)
- Expected Slave Device = xx
- Link Failure Timeout (ms) = 10000

→ OPERATING MODES:

- Operating Mode = Phase Mode
- Reading Phase ON = Ext. Trigger Leading Edge
- Acquisition Trigger = Continuous
- Reading Phase OFF = Input 2 Trailing Edge, Complete Read
- Image Acquisition Buffer Size = 20

→ CALIBRATION

- Exposure Time (x10us) =
- Gain =
- Gain Increasing = x1

Actual Calibration default parameter values depend on STS400™ model and can be modified to improve reading rate in the specific application.

→ IMAGE PROCESSING

- Processing Mode = Advanced Code Setting
- Image Processing Timeout (ms) ≥ 100

→ 1D CODES:

- Minimum Code Height (mm) = 5
- Tires Improvement = Method 2 (Sigma ROI) to optimize code location and minimize processing time in case of low height barcodes
- Code search priority = Horizontal/Vertical (even and odd Slave nodes alternate Horizontal/Vertical and 45 Degrees) to optimize code location in case of low height barcodes

→ DATA COLLECTION

- Minimum Phase Duration (ms) = (presence sensor debounce filter may be modified to eliminate false reading Phases)

SLAVE READERS CONFIGURATION

Same configuration as master except for the following:

➔ READING SYSTEM LAYOUT:

- Device Network Setting = Alone o ID-NET
- Topology Role = Slave (synchronized)
- Slave Address = 1,2,3, ...

➔ OPERATING MODES

- Acquisition Trigger Delay for SLAVES 1,3, 5,... (odd nodes)
Status = Enabled
Delay Time (x100us) = 20
- Acquisition Trigger Delay for SLAVES 2,4,... (even nodes)
Status = Disabled

➔ 1D CODES:

- Code search priority =
45 Degrees (odd nodes)
Horizontal/Vertical (even nodes)



NOTE: In addition to the above parameters, the master reader may require changes to the setup parameters that handle the communications between the STS400™ and the host computer. Refer to the Matrix 410 Reference Manual and VisiSet™ Help-On-Line for the details.

6.2 BACKUP & RESTORE PROCEDURES

The STS400™ factory default parameter settings are already stored in the External Memory (BM100 module) inside the CBX500 ATS connection box. After installation, changes to these parameters must be backed up, overwriting the factory settings.

Additionally, backup files can be created for each specific reader on the STS400™ and saved to a PC.

6.2.1 Using VisiSet™

The VisiSet™ configuration tool provides the most comprehensive method of calibration and system configuration is the preferred method for making parameter changes. It also provides an easy method for performing configuration Backup and Restore.

Backup Procedure

1. Make sure the Write Protection switch (inside the CBX500 ATS) on the BM100 is unlocked.
2. While VisiSet™ is connected to the Master reader, select the Backup item from the Device Menu in confirm by clicking the **Yes** button.
3. During the procedure, messages appear on the VisiSet™ terminal window showing the progress and at the end the final results.
4. Set the Write Protection switch on the BM100 to locked.

Restore Procedure

1. While VisiSet™ is connected to the Master reader, select the Restore item from the Device Menu in confirm by clicking the **Yes** button.
2. During the procedure, messages appear on the VisiSet™ terminal window showing the progress and at the end the final results.

Backup Files to PC

VisiSet™ also allows Backup to be performed through the ID-NET™ network to .ini files, saving them to the local PC. See the VisiSet™ Help On Line file under "ID-NET™ Backup to File Through Master" for details on this procedure.

6.2.2 Using CBX500 ATS HMI Interface (Keypad/Display)



Figure 21 – CBX500 ATS Keypad

Through the CBX500 ATS keypad and display, you can perform the Backup and Restore functions from the "Extended" menu. See chapter 4 for details on entering the Extended menu.

Backup Procedure

1. Make sure the Write Protection switch (inside the CBX500 ATS) on the BM100 is unlocked.
2. Select the Backup item from the Extended menu and press the Enter key on the **Yes** item.
3. When the procedure is complete a message appears on the display showing the results (**Done** or **Error**).
4. Set the Write Protection switch to locked.

Restore Procedure

1. Select the Restore item from the Extended menu and press the Enter key on the **Yes** item.
2. When the procedure is complete a message appears on the display showing the results (**Done** or **Error**).

7 MAINTENANCE

7.1 STS400™: WHAT YOU CAN AND CANNOT DO

The STS400™ comes pre-assembled, configured, calibrated and tested. Very few changes may be needed (and are allowed) to adapt the system to the plant operating conditions. **Several changes are not permitted and if they are carried out the warranty is automatically void.**

- If necessary, the readers' configuration can be altered, but this should be done only according to the indications in chapter 6.
- The Matrix 410™ ATS readers are self-contained units (unique part #) and must not be disassembled. In the event of a faulty unit, it must be replaced with another Matrix 410™ ATS.
- The Matrix 410™ ATS lens cover must not be unscrewed or removed. A warranty seal is present that voids warranty if broken.
- The Matrix 410™ ATS lens must not be tampered with to alter the focus/diaphragm adjustment.
- The Matrix 410™ ATS internal illuminator must not be unscrewed or removed.

7.2 CLEANING

Clean the reading windows periodically for continued correct operation of the array (see [General Views](#), 5).

Dust, dirt, etc. on the window may alter the reading performance.

Repeat the operation frequently in particularly dirty environments.

Use soft material and alcohol to clean the window and avoid any abrasive substances.

8 TROUBLESHOOTING

8.1 GENERAL GUIDELINES

- When wiring the device, pay careful attention to the signal name (acronym) on the CBX100/500 spring clamp connectors (chp. 3).
- If you need information about a certain reader parameter you can refer to the VisiSet™ program help files; either connect the device and select the parameter you're interested in by pressing the F1 key, or select **Help>Parameters Help** from the command menu.
- If you're unable to fix the problem and you're going to contact your local Datalogic office or Datalogic Partner or ARC, we suggest providing (if possible): Application Program version, Parameter Configuration file, Serial Number and Order Number of your reader. You can get this information while VisiSet™ is connected to the reader: the Application Program version is shown in the Terminal Window; the Parameter Configuration can be saved to an .ini file applying the **File>Save Configuration File** command in the Parameter Setup window; Serial Number and Order Number can be obtained by applying the respective command in the **Tools** menu.

Troubleshooting Guide for STS400™ Solutions	
Problem	Suggestion
Presence Sensor: the sensors (light barrier) is not working correctly.	• Check the LED's on the presence sensor. If the sensor has power, a green LED must be lit. If the sensor has a free path (view) to the reflector, only this green LED should be lit. If a yellow LED is lit together with the green one, please check the mechanical position and orientation of the sensor and reflector. • Every time the yellow LED on the sensor is lit, the corresponding LED in the CBX500 ATS connection box must be lit. For Trigger this must be the yellow LED and for Input 2 the green one. Is this is not the case, please check the wiring of the sensors.
No Presence Sensor: No trigger signal from the PLC (If no sensor is used.)	• Every time if a signal from PLC is correct in the CBX500 ATS connection box, a yellow LED (Trigger) must be lit inside of this box. If this is not the case, please check the wiring and the output of the PLC.
No Trigger Signal at Reader: Is the trigger signal correctly recognized by the readers?	• If a reading signal (trigger signal) is present and active from the sensor or PLC and the LEDs in the CBX500 ATS connection box are working correctly, the trigger signal LED on the reader must also be lit. As long as this LED is lit, the readers try to read a code. If this LED does not light, please replace the reader and send it to repair.
Does the internal lighting system work correctly?	• If a trigger signal is active and no code is present under the system, all readers must flash blue or red. If this is not the case please replace the reader and send it to repair.
Do the readers read codes?	• Place a correctly positioned code under each reader. If the reader has read the code, the its GOOD read (green) LED must light. Also a green spot must light at the code surface. If this is not the case, please replace the reader and send it to repair.

9 TECHNICAL FEATURES

ELECTRICAL FEATURES	
Power	
Supply Voltage	24 Vdc
Consumption	See par. 1.5
Communication Interfaces	
Main	
- RS232	2400 to 115200 bit/s
- RS485 full-duplex	2400 to 115200 bit/s
Auxiliary - RS232	2400 to 115200 bit/s
ID-NET™	Up to 1MBaud
Ethernet	10/100 Mbit/s
Inputs	
Input 1(External Trigger) and Input 2	Opto-coupled and polarity insensitive
Max. Voltage	30 Vdc
Max. Input Current	10 mA
Outputs	
Output 1 and Output 2	Opto-coupled
$V_{Out} (I_{Load} = 0 \text{ mA}) \text{ Max.}$	30 Vdc
$V_{Out} (I_{Load} = 10 \text{ mA}) \text{ Max.}$	1.8 Vdc
$P_D = V_{Out} \times I_{Load} \text{ Max.}$	170 mW
OPTICAL FEATURES	
Image Sensor	CCD
Image Format	UXGA (1600x1200)
Frame Rate	15 frames/sec.
Pitch	$\pm 35^\circ$
Tilt	$0^\circ - 360^\circ$
Lighting System	Internal Illuminator
LED Emmission	according to EN 62471
ENVIRONMENTAL FEATURES	
Operating Temperature	0 to 50 °C (32 to 122 °F)
Storage Temperature	-20 to 70 °C (-4 to 158 °F)
Max. Humidity	90% non condensing
Protection Class - EN 60529	IP65 *

* when correctly connected to cables with seals and protection caps.

PHYSICAL FEATURES		
Dimensions:		
STS400-0x4, -0x5, -0x6	785 x 223 x 149 mm (30.91 x 8.78 x 5.87 in.)	
STS400-1x5	785 x 241 x 176 mm (30.91 x 9.49 x 6.93 in.)	
STS400-1x6	800 x 241 x 176 mm (31.50 x 9.49 x 6.93 in.)	
STS400-0x7, -0x8	1065 x 223 x 149 mm (41.93 x 8.78 x 5.87 in.)	
STS400-1x7	1072 x 241 x 176 mm (42.20 x 9.49 x 6.93 in.)	
STS400-1x8	1080 x 241 x 176 mm (42.52 x 9.49 x 6.93 in.)	
Weight:		
Mounting Plate	4-6 readers 4100 g (9.04 lbs) 7-8 readers 5450 g (12.02 lbs)	
Reader + Bracket	Matrix 410 ATS-000 about 610 g (1.34 lbs) each Matrix 410 ATS-100 about 880 g (1.94 lbs) each	
Pre-mounted Cables	CAB-MS003 100 g (3.53 oz) each CAB-L003 66 g (2.33 oz) each	
ID-NET Cables and Terminator	CBL-1480-003 48 g (1.69 oz) each CBL-1490 Terminator 16 g (0.56 oz)	
QLs	QL100 115 g (4.06 oz) each QL150 123 g (4.34 oz) each	
To calculate the weight of your specific STS400 model, add the weights of the individual components from those listed above in the quantity present on your model.		
SOFTWARE FEATURES		
Readable Code Symbolologies		
1-D and stacked	2-D	POSTAL
• PDF417 Standard and Micro PDF417 • Code 128 (GS1-128) • Code 39 (Standard and Full ASCII) • Code 32 • MSI • Standard 2 of 5 • Matrix 2 of 5 • Interleaved 2 of 5 • Codabar • Code 93 • Pharmacode • EAN-8/13 - UPC-A/E (including Addon 2 and Addon 5) • GS1 DataBar Family • Composite Symbolologies	• Data Matrix ECC 200 (Standard, GS1 and Direct Marking) • QR Code (Standard and Direct Marking) • Micro QR Code • MAXICODE • Aztec Code	• Australia Post • Royal Mail 4 State Customer • Kix Code • Japan Post • PLANET • POSTNET • POSTNET (+BB) • Intelligent Mail • Swedish Post
Operating Mode	PHASE MODE	
Configuration Methods	Windows-based SW (VisiSet™) via serial or Ethernet link Serial Host Mode Programming sequences	
Parameter Storage	Permanent memory (Flash)	
USER INTERFACE		
LED Indicators	Power, Ready, Good; Trigger; Com, Status, (Ethernet Network); (Green Spot)	



Datalogic Automation S.r.l.

Via Lavino 265
40050 Monte San Pietro
Bologna - Italy

declares that the

**MATRIX 410; 2D Imager
MATRIX 410N; 2D Imager**

and all its models

are in conformity with the requirements of the European Council Directives listed below:

2004 / 108 / EC EMC Directive

This Declaration is based upon compliance of the products to the following standards:

EN 55022 (CLASS A ITE), DECEMBER 2010:

INFORMATION TECHNOLOGY EQUIPMENT
RADIO DISTURBANCE CHARACTERISTICS
LIMITS AND METHODS OF MEASUREMENTS

EN 61000-6-2, SEPTEMBER 2005:

ELECTROMAGNETIC COMPATIBILITY (EMC)
PART 6-2: GENERIC STANDARDS - IMMUNITY FOR INDUSTRIAL
ENVIRONMENTS

Monte San Pietro, September 23th, 2014

Paolo Morselli
Quality Manager

Morselli Paolo



**Datalogic Automation S.r.l.**

Via Lavino 265

40050 Monte San Pietro

Bologna - Italy

www.automation.datalogic.com*declares that the***CBX100; Connection Box Compact****CBX500; Connection Box Modular****BM100; Backup module****BM150; Display module***and all its models**are in conformity with the requirements of the European Council Directives listed below:***2004 / 108 / EC EMC Directive***This Declaration is based upon compliance of the products to the following standards:***EN 55022 (CLASS A ITE), DECEMBER 2010:***INFORMATION TECHNOLOGY EQUIPMENT
RADIO DISTURBANCE CHARACTERISTICS
LIMITS AND METHODS OF MEASUREMENTS***EN 61000-6-2, SEPTEMBER 2005:***ELECTROMAGNETIC COMPATIBILITY (EMC)
PART 6-2: GENERIC STANDARDS - IMMUNITY FOR INDUSTRIAL
ENVIRONMENTS*

Monte San Pietro, January 20th, 2012

Paolo Morselli
Quality Manager

**Datalogic Automation S.r.l.**

Via Lavino 265

40050 Monte San Pietro

Bologna - Italy

www.automation.datalogic.com*declares that the***QLxxx and QLMxxx; Connection module***and all its models**are in conformity with the requirements of the European Council Directives listed below:***2004 / 108 / EC EMC Directive***This Declaration is based upon compliance of the products to the following standards:***EN 55022 (CLASS A ITE), DECEMBER 2010:**INFORMATION TECHNOLOGY EQUIPMENT
RADIO DISTURBANCE CHARACTERISTICS
LIMITS AND METHODS OF MEASUREMENTS**EN 61000-6-2, SEPTEMBER 2005:**ELECTROMAGNETIC COMPATIBILITY (EMC)
PART 6-2: GENERIC STANDARDS - IMMUNITY FOR INDUSTRIAL
ENVIRONMENTS

Monte San Pietro, January 20th , 2012

Paolo Morselli
Quality Manager



 **DATALOGIC**

www.datalogic.com