Yeovil Desk





Inspired by Scandinavian designs, the Yeovil desk is as stylish and on trend as they come. The beautifully angled design matches perfectly with the white and oak finish, whilst the drawers and shelving ensure the Yeovil is practical too. The Yeovil features rear cable management and raised monitor shelf, giving this classic writing desk a place in the modern world.

- · Complementing oak and white finish
- Scandinavian inspired design
- 2 drawers and shelves
- Raised monitor mount Rear cable management
- Working area (mm): W 1150 x D 405






Yeovil Desk



Technical Sheet



PACKAGING		
Number of Boxes		1
Width	(mm)	1310
Height	(mm)	150
Depth	(mm)	645
Weight	(kg)	30





AW3180 EAN: 5060669112549










PLEASE INSPECT ALL PARTS PRIOR TO ASSEMBLY AND CONTACT US IF ANY OF THE PARTS ARE DAMAGE OR MISSING. THIS MUST BE DONE BEFORE ATTEMPTING ASSEMBLY.

Thank you for purchasing this Yeovil Desk. Please read the instructions carefully before assembly and use to ensure safe and satisfactory operation of this product.





Notes: Some of tools shown here are optional and are required only for quick assembly of this product


Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.


This product is HEAVY, it should be assembled as near as possible to the point of use. TAKE CARE WHEN LIFTING to avoid personal injury and(or) damage to the product.


This product takes approximately 60MINUTES to assemble with 2 PEOPLE.


The fittings pack contains SMALL ITEMS which should be KEPT AWAY FROM YOUNG CHILDREN.


Read this leaflet in full before commencing assembly.

















































How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its luster.

Spray polishers are best avoided as the contain silicons which may spoil the furniture's surface by building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coaster. Wipe up spills immediately and ensure that a mat or a pad is placed under paper if you are writing.

Extendable dining tables should be left extended for the first few months to avoid an uneven appearance. Likewise, lamps and ornaments should also be moved regularly.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by hearing can cause damage such as warping.

Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFEREENCE