

# Ohio Barstool

alphason


The Ohio is a simple yet attractive barstool made from leather, on a beautiful chrome frame and footrest. It features 360 turning and seat height adjustment, with the padded, leather seat shaped for maximum comfort.

- Low back leather barstool
- Chrome base and footrest
- 360° Swivel
- Height adjustable
- Seat Dims (mm):  
H 580-780 x W 400 x D 440



Seat Height  
Adjustment

# Ohio Barstool



**ABS249-BLK BLACK**  
**EAN: 5030752017631**




**ABS249-GRY GREY**  
**EAN: 5060669115670**

**alphason**

Technical Sheet

SPECIFYING	
Seat Height (mm)	580-780
Max. User Weight (kg)	114
Max. Recommended Use (hours)	2
Product Weight (kg)	6.4
Dims: H 855 x W 405 x D 440 (mm)	

PACKAGING	
Number of Boxes	1
Width (mm)	405
Height (mm)	855
Depth (mm)	440
Weight (kg)	7.5



PLACE LABEL  
Q14171-SK  
HERE



01942 524100



CSEurope@dorel.com



Dorel Home Furnishings Europe Ltd.  
Building 4, Imperial Place, Maxwell Road, Borehamwood WD6 1JN

**Thank you for purchasing this chair. Please inspect all parts prior to assembly and contact us if there are any damaged or missing components. This must be done before attempting assembly.**

## **Pre-assembly preparation**

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately 15 MINUTES to assemble with 1 PERSON.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly to ensure safe and satisfactory operation of this product.

## **Safety Instructions**

Never drag furniture when moving it, always lift it.


Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

Never tilt the chair. Ensure the chair is always placed firmly on the ground.



## **WARNING :**

Sit on the chair to use the weight of the body to tighten the joint on the column and the seat.

Please note this is not a permanent fit due to the rise & fall and 360 degree turning action.


Always take care and keep feet clear of base when moving / lifting this product.

Do not stand on chair as this may cause serious injury.

Do not use the chair if any part appears damaged, broken or missing.


Do not use the chair unless all components are correctly fitted and adjusted.

Only trained personnel may replace or repair seat height adjustment components with energy accumulators.



**PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE**

**DOREL HOME ACCEPTS NO LIABILITY FOR ANY DAMAGE CAUSED THROUGH INCORRECT OR INAPPROPRIATE USE OF THIS PRODUCT.**



**E** x4



M5/x1PC

