



2W06302

PREMIUM RINSE AID

Cutlery • Crockery • Plates
Utensils • Glassware

USES

A premium quality rinse aid additive which prevent spots and hazing for a consistently sparkling finish.



A thin, clear blue liquid, *Premium Rinse Aid* is a blend of specialist surfactants and mild acids in a taint-free aqueous base.

Ideal to ensure a perfect finish on plates, crockery, cutlery, utensils, glassware, glasses and tumblers.


Suitable for automatic dish washing machines in all food and catering establishments, e.g. cafés, restaurants, hotel kitchens, canteens, etc.

DIRECTIONS

Feed into the machine through the automatic dosing system if one is fitted. Otherwise, add to the rinse cycle at a dilution rate of 1 part *Premium Rinse Aid* to 900 parts rinse water.



AREAS OF USE



Plates / Cutlery

DILUTIONS

PREMIUM RINSE AID : WATER

1:900



1st Floor, 1 Europa Drive,
Sheffield, S9 1XT T:0844 980 8000 www.2worksupplies.co.uk

pH in use

