

# RINSE AID

- Sparkling finish
- Prevents spots and hazing
- Suitable for all types of glass and dishwasher machines

## USES

A rinse additive for all automatic dish and glass washing machines. Prevents spots and hazing on crockery and glassware, leaving a sparkling finish.

*Rinse Aid* is mildly acidic to neutralise detergent deposits.


Suitable for use through automatic dosing equipment or by manual dosing.

## DIRECTIONS

Feed into the machine through the automatic dosing system if one is fitted. Otherwise add to the rinse cycle at a dilution rate of 1 part *Rinse Aid* to 600 parts of rinse water.



## AREAS OF USE



Plates/  
Cutlery

## DILUTIONS

RINSE AID : WATER	1:600
-------------------	-------

