#### 1. Disassembly Procedures

- S1 Turn off power
- S2 To remove the stand

Place the monitor on U3415W Curve Sponge Jig

1

Press and hold the stand release button at the back of the display.

Lift the stand up and away from the monitor.



S3 Unlock 4 screws



(Screw Torque: 11±1Kgf)



Use hands or scraper bar to disassemble Rear Cover from the monitor.

Notice the disassembly order: Left Side=> Top Side=>Right Side=>Bottom Side



S5 Unplug "CTRL BD FFC" from I/F BD





Tear off 1 tape from "CTRL BD FFC"

Tear off "CTRL BD FFC" from Rear Cover



**S**7

Unlock 3 screws from CTRL BD and disassemble CTRL BD from Rear Cover



(Screw Torque: 1.5-2.0 Kgf)

**S8** Tear off Mylar from CTRL BD (See yellow mark)

Unplug "CTRL BD FFC" from CTRL BD



S9 Unplug USB FFC from I/F BD

Unlock 1 screw and disassemble USB BD from Middle Frame

Unplug USB FFC from USB BD



(Screw Torque: 4.0-4.5 Kgf)

**S10** Tear off a gasket from panel (See yellow mark)

Tear off 2 tapes from backlight wires (See blue mark)

Unplug backlight wires from LED Driver BD (See red mark)

Unlock 13 MF screws



(Screw Torque: 4.0-4.5 Kgf)

S11 Unlock 3 MF screws

Unlock 2 screws to disassemble "BOSS PANEL" (see red mark)

Disassemble 2 pieces of "BOSS PANEL" from panel (see red mark)

Disassemble Middle Frame from panel



(Screw Torque: 4.0-4.5 Kgf)

## DELL P3424WEB 3

S12 Unlock 4 screws to disassemble Main SHD



(Screw Torque: 4.0-4.5 Kgf)

S13

Tear off 1 acetate tape and 1 yellow tape from EDP FFC



**S14** Unplug EDP FFC from panel Take off Main SHD from Panel



**S15** Tear off 3 tapes from backlight wire (see yellow mark)

Tear off 4 tapes from backlight wire (see blue mark)

Unplug long backlight wire from panel



S16 Unplug short backlight wire from panel



S17 Tear off logo from panel



S18 Disassemble Mylar from SHD



S19 Unlock 10 PCBA screws



**S20** Disassemble I/F BD from Main SHD and unplug SPS BD wire from I/F BD

Tear off 1 tape from EDP FFC and unplug EDP FFC from I/F BD

Disassemble LED Driver BD from Main SHD and unplug "WIRE 8P/8P" from LED Driver BD

Disassemble SPS BD from Main SHD and unplug "WIRE 8P/8P" from SPS BD







# DELL P3424WEB

S21 Remove electrolyte capacitors (red mark) from printed circuit boards



5

S21-1 Cut the glue between bulk cap. and PCB with a knife



S21-2 Ensure cutting path within the glue, don't touch bulk cap. or PCB



S21-3 Take out bulk cap. pin solder with soldering iron and absorber



S21-4 Lift the bulk cap. up and away from the PCB



### 2. Product material information

The following substances, preparations, or components should be disposed of or recovered separately from other WEEE in compliance with Article 4 of EU Council Directive 75/442/EEC.

| Capacitors / condensers (containing<br>PCB/PCT) | No used                                |
|---|--|
| Mercury containing components                   | No used                                |
| Batteries                                       | No used                                |
| Printed circuit boards (with a surface greater  | Product has printed circuit boards     |
| than 10 square cm)                              | (with a surface greater than 10 square |
|   | cm)                                    |
| Component contain toner, ink and liquids        | No used                                |
| Plastic containing BFR                          | No used                                |
| Component and waste contain asbestos            | No used                                |
| CRT   | No used                                |
| Component contain CFC, HCFC, HFC and            | No used                                |
| HC  |  |
| Gas discharge lamps                             | No used                                |
| LCD display > 100 cm2                           | Product has an LCD greater than 100    |
|   | cm2                                    |
| External electric cable                         | Product has external cables            |
| Component contain refractory ceramic fibers     | No used                                |
| Component contain radio-active substances       | No used                                |
| Electrolyte capacitors (height                  | Product has electrolyte capacitors     |
| > 25mm, diameter > 25mm)                        | (height >25mm, diameter > 25mm)        |

### 3. Tools Required

List the type and size of the tools that would typically can be used to disassemble the product to a point where components and materials requiring selective treatment can be removed.

Tool Description:

- Philips-head Screwdriver
- Penknife
- Bar scraper
- U3415W Curve Sponge Jig