

If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.





backspace

enter

shift

pqup

padn

home


end

Note: For the best wireless experience, we recommend using the extension adapter for receiver and putting the 2.4GHz receiver somewhere on your desk close to your keyboard for a low rate of latency and fewer signal interferences






#### Switch toggle to Cable



# **5** The Backlight

Press fn + Q to change the lighting effect




## Press fn + tab to turn the backlight on/off




## 7 Adjust The Backlight Speed

Press fn + T to increase the light effect speed



#### Press fn + G to decrease the light effect speed



#### 9 Watch The Building Tutorial On Our Website

If you are building the keyboard for the first time, we highly recommend you watch the building tutorial video on our website first, then start building the keyboard yourself.



#### 4 The VIA Key Remapping Software


Please visit <u>usevia.app</u> to use the online VIA software to remap the keys. If the VIA cannot recognize your keyboard, please reach our support to get the instruction.



- \* The online VIA software can only run on the latest version of Chrome, Edge, and Opera browsers yet.
- \* VIA only works when the keyboard is connected by wire to the computer.

# 6 Adjust The Backlight Brightness

#### Press fn + W to increase the backlight brightness



Press fn + S to decrease the backlight brightness



#### 8 Warranty

The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.



### 10 Factory Reset

Not Happy



Troubleshooting? Don't know what's going on with the keyboard?

- 1. Download the right firmware and QMK Toolbox from our website.
- Unplug the power cable and switch the keyboard to Cable mode.
- Remove the space bar keycap to find the reset button on the PCB.
- 4. Hold the reset key first, then plug the power cable into the keyboard. Release the reset key after 2 seconds, and the keyboard will now enter
- 5. Flash the firmware with the OMK Toolbox.

DFU mode

- 6. Factory reset the keyboard by pressing fn + J + Z (for 4 seconds).
- \* Step by step guide can be found on our website.