INSTALLATION INSTRUCTIONS



55" to 40" Free-Standing Kiosk Base/ 55" to 40" Free-Standing Kiosk Back-to-Back Base



A brand of **L1 legrand**

DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Legrand AV Inc.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all accessories are properly assembled and installed using the instructions provided.

WARNING: Failure to provide adequate structural strength for this accessory can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this accessory is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the accessory.



WARNING: Use this accessory only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

WARNING: Never operate this accessory if it is damaged. Return the accessory to a service center for examination and repair.

WARNING: Do not use this accessory outdoors.

--SAVE THESE INSTRUCTIONS--

DIMENSIONS





LEGEND

	Tighten Fastener	Pencil Mark
	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
Ð	Kreuzschlitzschraubendreher	Einstellen
		Ajustar
	Chave de fendas Phillips Cacciavite a stella	
		Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
6/	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
E E	Chave de bocas	Remover
0 0	Chiave a punte aperte	Rimuovere
0	Chiave a punte aperte Steeksleutel	Rimuovere Verwijderen
Ŭ O	Chiave a punte aperte	Rimuovere
Ö	Chiave a punte aperte Steeksleutel	Rimuovere Verwijderen
0	Chiave a punte aperte Steeksleutel Clé à fourche	Rimuovere Verwijderen Retirez
0	Chiave a punte aperte Steeksleutel Clé à fourche By Hand	Rimuovere Verwijderen Retirez Optional
0 K	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano	Rimuovere Verwijderen Retirez Optional Opcional
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand	Rimuovere Verwijderen Retirez Optional Opcional Optional
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão	Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano	Rimuovere Verwijderen Retirez Optional Optional Optional Optional Optional Optional Optional Optional
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand	Rimuovere Verwijderen Retirez Optional Optional Optional Opcional Opzionale Optie En option
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench	Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Optie En option Security Wrench
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main	Rimuovere Verwijderen Retirez Optional Optional Optional Opcional Opzionale Optie En option
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel	Rimuovere Verwijderen Retirez Optional Opcional Optional Opcional Opcional Optional Optional Optional Optional Optional Optional Special Optional Special Optional Sicherheitsschlüssel
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada	Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opzionale Optie En option Security Wrench Llave de seguridad
	Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel	Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Opcional Opcional Optio En option Sicherheitsschlüssel Chave de segurança

TOOLS REQUIRED FOR INSTALLATION







DISASSEMBLY OF SHIPPED PARTS

1. Remove the fasteners holding the base pieces together. (See Figure 1)

IMPORTANT ! : Save the washers, and discard the spacers and screws.



Figure 1

ASSEMBLY OF PACLFx / PACLFx-B2B

IMPORTANT ! : When assembling the base, the fasteners are placed in different holes depending upon whether you are using the PACLFx / PACLFx-B2B for a 48" - 40" kiosk or a 55" - 49" kiosk. (See Figure 4) and (See Figure 5)

- 1. Place rectangular pieces of base on floor, lining up opening area on each piece. (See Figure 2) and (See Figure 3)
- 2. Lower remaining section of base onto two rectangular sections, lining up screw holes and opening as shown. (See Figure 2) and (See Figure 3)
- 3. Insert sixteen 5/16 x 1/2" button head screws (B) into highlighted holes and tighten.



Figure 2



Figure 3

IMPORTANT ! : (See Figure 4) for 48" - 40" kiosks, and (See Figure 5) for 55" - 49" kiosks.



Figure 4



Figure 5

Attaching Kiosk to Free-Standing Base

1. Place kiosk onto base, lining up mounting holes on kiosk and base. (See Figure 4) and (See Figure 5)



Figure 6

 Fasten kiosk to base using four 5/16 x 1/2" button head screws (B) and washers removed in Step 1 of Disassembly of Shipped Parts section. (See Figure 6)



A brand of Liegrand

8800-003195 Rev00 ©2020 Legrand | AV www.legrandav.com 05/2020

Europe

Asia Pacific

- USA/International A 6436 City West Parkway, Eden Prairie, MN 55344
 - P 800.582.6480 / 952.225.6000
 - **F** 877.894.6918 / 952.894.6918
 - A Franklinstraat 14, 6003 DK Weert, Netherlands
 - Ρ +31 (0) 495 580 852
 - **F** +31 (0) 495 580 845
 - A Office No. 918 on 9/F, Shatin Galleria 18-24 Shan Mei Street Fotan, Shatin, Hong Kong
 - **P** 852 2145 4099
 - F 852 2145 4477

