

# **PRODUCT HIGHLIGHTS**

- Stereo sound with a bi-directional speaker
- High power: 1500 watts
- Built-in woofer for sound you can feel
- Color-changing LED lights
- Karaoke Mode with 2 mic inputs

Take your party to the next level with 1500 watts of high power audio. Go ahead; turn it up and keep your party going with massive sound.

#### **KEY FEATURES**

#### **BI-DIRECTIONAL SOUND**

Go wall to wall with a unique bi-directional design. It delivers your music to a wider area for a room-filling sound experience.

# **BUILT-IN WOOFER**

Energize the room with a 10-inch built-in woofer. You won't just hear it, you'll feel it.

#### **DYNAMIC BASS**

Press the Bass Booster button to power up the party with a touch of a button.

# LED PARTY LIGHTS

Light up the party with fun light modes, including Party, Ambient and Dance. Set the lighting effect to match the rhythm and get dancing.

## KARAOKE MODE

You and a friend can get the whole party singing with Karaoke Mode. Belt out every word with two mic inputs.

# GIGA PARTY AUDIO APP

Control your party! Download the app¹ to adjust the built-in LED lighting, sound effects and even your EQ settings—right from your Android or iOS device. Party on!

#### **BLUETOOTH® MULTI-CONNECTION**

Friends who dance together stay together. With Bluetooth® Multi-Connection, you and your friend can connect and pair two mobile devices simultaneously. Alternate between two separate devices without disconnecting.

### **GROUP PLAY**

Fill the entire room by connecting multiple Samsung Giga Party Audio devices for a more immersive sound experience.<sup>2</sup>

#### SPLASH RESISTANCE

With a splash-resistant top panel, you don't have to worry about accidental drips and splashes. Just enjoy the party!

# **MODEL**

**MODEL:** MX-T70

UPC CODE: 887276384184

# **DIMENSIONS (INCHES H x W x D):**

• **PARTY AUDIO:** 34.8 x 18.2 x 17.9

PACKAGING: 36.9 x 22.2 x 20.6

#### WEIGHT (LB):

PARTY AUDIO: 58.4
PACKAGING: 66.1

### **AUDIO:**

- NUMBER OF CHANNELS: 2CH
- TOTAL WATTAGE: 1500W
- BASS BOOSTER BUTTON
- BUILT-IN SUBWOOFER
- SOUND MODES: PARTY, STANDARD (MONO), HIP-HOP, EDM, ROCK, LATIN, HOUSE, REGGAE
- KARAOKE: YES (2 MIC INPUTS)

# **SPECIAL FEATURES:**

- PARTY LIGHTING: PARTY, AMBIENT, DANCE, THUNDERBOLT, STAR, LOVER
- SAMSUNG GIGA PARTY AUDIO APP: COMPATIBLE WITH ANDROID MOBILE DEVICES RUNNING OS 6.0 AND APPLE MOBILE DEVICES RUNNING iOS 10.0 OR LATER.
- **DJ EFFECT:** NOISE, FILTER, CRUSH, CHORUS, WAHWAH

#### **AV DECODING:**

- AAC
- MP3
- WAV
- WMA
- FLAC

# **CONNECTIVITY:**

- 2 USB CONNECTORS (TYPE-A)
- ANALOG AUDIO INPUT (3.5MM)
- BLUETOOTH®
- BLUETOOTH® MULTI-CONNECTION
- WIRED GROUP PARTY PLAY
- WIRELESS GROUP PARTY PLAY

#### **ACCESSORIES INCLUDED IN BOX:**

- REMOTE CONTROLLER
- BATTERY FOR REMOTE CONTROLLER