

CRF
250 RALLY

**ADVENTURE
EVERYWHERE**




HONDA
One HEART.

CRF

250 RALLY

BUILT FOR ADVENTURE
250 CC DOHC ENGINE
 LIQUID-COOLED, 4-STROKE, 4-VALVE, 6-SPEED
WITH ASSIST/SLIPPER CLUTCH



**NOW WITH
 ANTI-LOCK
 BRAKING SYSTEM**

FULL DIGITAL PANEL METER

FUEL TANK

HANDGUARD

**LED
 HEADLIGHT**

**INVERTED TELESCOPIC
 FRONT SUSPENSION WITH
 WAVY DISK BRAKE**

ALUMINIUM SWING ARM WITH PRO LINK REAR SUSPENSION



SPECIFICATION

DIMENSION

Overall (L x W x H)	2,229 x 920 x 1,419 mm
Wheelbase	1,453 mm
Ground Clearance	277 mm
Seat Height	893 mm
Curb Mass	152 kg
Fuel Tank Capacity	12.8 l

ENGINE

Engine Type	4-Stroke, DOHC, 4-Valve, Single Cylinder
Cooling System	Liquid-cooled
Fuel Supply System	PGM-FI (Programmed Fuel Injection System)
Displacement	249,67 cc
Bore x Stroke	76 mm x 55 mm
Compression Ratio	10.7
Maximum Power	18,3 kW / 9,000 rpm
Maximum Torque	23.0 Nm / 6,500 rpm
Transmission	6-Speed Manual

Gear Shift Pattern	1-N-2-3-4-5-6
Starting System	Electric
Clutch System	Wet, Multi-plate Wet Clutch
Lubricant Type	Wet
Oil Capacity	1,4 liters (Periodic exchange)

FRAME

Frame Type	Semi-Double Cradle, Steel
Tire Size	Front 80/100 - 21M/C 51P
	Rear 120/80 - 18M/C 62P

Brake Type	ABS System Type ABS
	Front 296 mm, Wavy Disc Brake
	Rear 220 mm, Wavy Disc Brake
Suspension Type	Front Showa, 43 mm, Inverted Telescopic
	Rear Showa, Pro-Link

ELECTRICAL

Ignition Type	Full Transisterized
Battery	MF-Wet 12V-7Ah (10H)
Spark Plug Type	NGK SIMR8A9
Headlight	LED



EXTREME RED



#CARI_aman
 saat naik motor

Gunakan selalu helm, pasang tali pengikat dan kencangkan secara benar

Gunakan jaket lengan panjang dan sarung tangan yang dirancang untuk keselamatan dan kenyamanan berkendara

Pakai lah celana panjang yang pas dan nyaman serta gunakan sepatu untuk kestabilan saat kaki berpijak

Produk Dapat Dibeli di Dealer:



Honda Customer Care
 ☎ 1-500-989
 ✉ 0811-9-500-989
 customercare@astra-honda.com
 www.astra-honda.com

Follow Us:

📱 wellovehonda indonesia
 📺 wellovehonda
 📷 wellovehonda_id
 📺 wellovehonda indonesia

www.astra-honda.com

Cara Perawatan yang Aman:

- Periksa tinggi permukaan oli dan gunakan selalu AHM Oil.
- Periksa rem dan tekanan udara ban.
- Gunakan Honda Genuine Parts, suku cadang asli sepeda motor Honda yang didistribusikan oleh PT Astra Honda Motor.
- Lakukan perawatan teratur di bengkel-bengkel resmi Honda (AHASS).

AHM
 PT Astra Honda Motor



AHM OIL
 Oli Asli Motor Honda



Honda Genuine Parts
 Suku Cadang Asli Motor Honda

