

Nondestructive evaluation of stresses and stress-related defects in gears

James Thomas, General Manager, American Stress Technologies

Gear manufacturing involves a number of processes that, intentional or not, affect the residual stress state of the critical surfaces. Stresses, including residual stresses from processing, are commutative, with compressive stresses typically improving fatigue life and crack initiation while tensile stresses do the opposite. Accordingly, gear designers and manufacturers often require compressive residual stresses at the surface on critical geometries such as gear teeth and roots.

Shot Peening Verification

Shot peening is a common process utilized in gear manufacturing to increase the amount of compressive stress and, consequently, increase the fatigue life of the gear. Often applied in the root area, shot peening involves blasting the surface of a component with hard “shot” (Fig. 1). A thin layer of the component is deformed and compressed while the core, or deep sub-surface volume, resists this compression (Fig. 2).

The result of this process is a layer of compressive stresses from the surface through some depth often a few hundred micrometers deep (Fig. 3).

There are a variety of methods to verify the shot peening process including the Almen strip test, visual analysis including the use of tracer dyes, and direct measurement of induced stresses. It is the latter method, measurement of induced stresses, which provides the only true objective measure which can be compared to expected values from the design and modeling phases. The best and most standardized method for the measurement of stresses is X-ray Diffraction (XRD).




Figure 1 Shot peening involves blasting the surface of a component with hard “shot.”




Figure 2 Shot peening results in a thin layer of compressive residual stress.




Figure 3 The compressive residual stress from shot peening can be a few hundred micrometers deep.

XRD for residual stresses is not a new method nor is it under the radar. It is a quantitative, standardized method with no true peers, especially when measuring nondestructively (measuring subsurface stresses requires layer removal). The XRD method has had some limitations as it can be expensive,




Figure 4 The Stresstech Xstress DR45 system.

time-consuming, and/or require costly sample preparation. Measurements could take minutes to hours, depending on the spot size and the equipment utilized. Generational leaps in technology, though, have changed this for the better and measurements can now be performed in seconds.

The Stresstech Xstress DR45 system (Fig. 4), utilizing state-of-the-art detector technology, is sensitive enough to make previously slow measurements lightning fast, or previously difficult measurements easy. Utilizing high-sensitivity 2D detectors, the DR45 measures so fast that it doesn't even need to stop moving to collect diffraction data.

Traditional diffractometers tailored to measure residual stresses, including Stresstech's prior offerings, often utilized 1D detectors. The use of more modern 2D detectors with improved sensitivity allows for significantly more diffraction data, as much as 100x, to be collected in the same amount of time. Sections of the 2D Debye-Scherrer ring are integrated into 1D intensity spectra for strain determination (Fig. 5).




Figure 5 The use of 2D detectors allows for the collection of significantly more diffraction data.


COMPACT. CONSISTENT. COMPETITIVE.

kapp-niles.com



AMB
 13.-17.09.2022
 Messe Stuttgart
 Hall 5 | Booth 5B11

KAPP NILES
 precision for motion



KISSsoft AG/Gleason Sales
 Brian P. Stringer
 Phone (585) 494-2470
 info@KISSsoft.com

NEW
 Release
 2022

KISSsoft Features

- Influence of flank waviness on transmission error
- Tooth root fatigue strength from time series
- Bearing contact stress with modified raceways
- Bearing inner geometry from Schaeffler and Timken
- Optimized bolt module interface

Trial version requests via www.KISSsoft.com

Drivetrain Design Solutions **KISSsoft**




Figure 6 Standard mode x-ray diffraction systems use a time-consuming sequence of individual scans.




Figure 7 The Xstress DR45 is able to scan continuously, greatly improving inspection speed.




Figure 8 Aggressive feeds and speeds can result in grinding burn.

In addition to improving the sensitivity and speed of the system, the 2D detector method employed by the Xstress DR45 combines the benefits of 2D detection systems, such as mitigation of difficult diffracting conditions like textured or large grains, with the high quality and trusted results of the $\sin^2\psi$ method. Beyond that, the multiple orders of magnitude improvement in speed allows for some truly game-changing capabilities: continuous movement measurements (or Sweep mode).

Diffraction systems utilizing the tried-and-true $\sin^2\psi$ method have always followed a standard sequence of operation (or Standard mode, shown in Figure 6): 1, move X-ray incident beam and detectors to position; 2, Expose the sample and collect diffraction data with detector; 3, Repeat 1–2 as necessary to satisfy the measurement specification such as EN15305. This type of measurement sequence is standard on nearly all diffractometers except for systems utilizing methods not in accordance with internationally recognized standards.

The speed of the detection system on the Xstress DR45 allows the diffractometer to collect “snapshots,” much like video frames, while it is moving (Fig. 7).

The result is a large improvement in total measurement speed over the already fast Standard mode speed provided by the Xstress DR45. Measurements on spots 1 mm in diameter or larger are performed in 5 seconds. Measurements on spots less than 0.5 mm in diameter can be performed in as little as 20 seconds. These speeds open the possibility of shot peen verification on gear teeth or roots which is fast enough to keep up with production in high-volume environments.

Material	Radiation	Mode	Time	Collimator diameter				
				3 mm	12 mm	1 mm	0.5 mm	0.3 mm
Ferritic steel INCONEL®	Cr Ka Mn Ka Cr Kf3	sweep	tsweep	5s	5s	5s	10s	20s
		standard	tmeas	34s	34s	34s	34s	34s
INCONEL°	Cr Ka Mn Ka Cr Kf3	sweep	tsweep	10s	10s	10s	20s	40s
		standard	tmeas	34s	34s	43s	70s	115s

Grinding Burn Detection

Grinding is a crucial step in gear manufacturing, and it frequently presents manufacturers with a critical question: How fast can I grind without generating a grinding burn? Faster cycle times are always desirable but greater infeed, wheel speed, etc. can result in more energy, or heat, being deposited into the workpiece (Fig. 8).

Grinding burn occurs when the heat generated in the workpiece during grinding is great enough to act as a tempering process or, in the case of even higher temperature, a re-heat treatment of the affected surface. The result of this localized thermal event is a transformation of the microstructure, much the same as what occurs during heat treatment. The affected volume of material is transformed from a desirable microstructure, such as tempered martensite, to an undesirable mix of over-tempered martensite (or softer ferrite, etc.) and untempered martensite. The transformed microstructures have differing densities but, squeezed into the same space previously occupied by the desirable microstructure, then must be compressed and/or

pulled apart in order to fit. This compressing or pulling manifests as residual stresses in the material.

The traditional method for detection of grinding burn is the Nital etch process. Nital etching involves exposing the surface of the material to different chemicals, including Nital (nitric acid and alcohol) and hydrochloric acid. The process takes advantage of differential dissolution, where the Nital mixture attacks phases such as ferrite, cementite, etc. differently. The result is that some visual contrast exists between the desirable tempered martensite microstructure and the undesirable over-tempered or untempered generated by grinding burn.

Though it is a traditional method with decades of use the Nital etching process has some downsides: it is subjective, requiring the practitioner to interpret literal shades of gray; it requires the use of possibly dangerous chemicals, often with nontrivial handling and disposal requirements; in most cases it is destructive, as etched surfaces may not be suitable for use in service. Another limitation inherent to the Nital etch process is that it is insensitive to stresses—its mechanism of action is to reveal transformed microstructure. In the case where grinding burn occurs during a roughing pass, only to be partially cleaned up by a finish pass, the Nital etch process can be ineffective at revealing the partially cleaned up transformation products. Despite partial cleanup of the transformed layer, subsurface tensile stresses typically remain. This “hidden” burn leaves the component susceptible to early failure. Stresses induced via grinding burn typically peak at 20–50 micrometers below the surface. In the case of partial cleanup of grinding burn during the grinding process a subsurface tensile peak typically remains (Fig. 9).

An alternative method to detect grinding burn is Magnetic Barkhausen Noise (MBN). It is a repeatable, objective measure that is nondestructive (Fig. 10). Furthermore, MBN is sensitive to both stresses and microstructure in the measured volume which makes it ideally suited for detection of grinding burn in cases of partial cleanup.

Stresstech’s Rollscan Barkhausen Noise analyzers take the MBN signal and reduce it to a single number measured in real-time. This allows the user to traverse an MBN sensor across a surface, manually or via automation, and get a live measurement or even a surface map.




Figure 9 Nital etch can sometimes miss some forms of grinding burn.



Figure 10 Magnetic Barkhausen noise analysis is an alternative to detect grinding burn.




Figure 11 Stresstech EasyGear software for programming of automated gear testing.




Figure 12 MBN instruments can measure gear flanks, roots, faces, ODs and IDs.




Figure 13 Customized sensors can be used, depending on the surface to be measured.




Figure 14 Complex geometries can be accommodated via special sensors and point-by-point control of the sensor path.




Figure 15 In this chart, the red line represents MBN signal increases, indicating the presence of grinding burn.




Figure 16 Multiple scans or passes per flank can be combined into a surface map.




Figure 17 Data from MBN scans can be shown against simple rejection/acceptance criteria for easy evaluation.

Automated systems are programmed in the same manner as an analytical gear checker with the ability to map the surface of the flank to the level of spatial resolution required for the application by utilizing Stresstech’s EasyGear software (Fig. 11). Gear flanks and roots, along with various other surfaces such as faces, ODs, and IDs are all measurable with MBN instruments (Fig. 12).

Customized sensors are sometimes required depending on the geometry of the surface to be inspected. For example, gear flanks and gear roots are typically measured with dedicated sensors which facilitate the sensor contacting the area of interest (Fig. 13).

In the case of more complex geometries, such as hypoid gears, custom sensors are utilized, and sensor movement paths are generated along complex curves generated point-by-point (Fig. 14).

The result of a measurement sequence is a series of scans, or plots, similar to the output of an analytical gear checker. Lower and more consistent measurement values, essentially flat scans, are typically found in acceptable parts free of grinding burn (see the green line in Figure 15). In the presence of a grinding burn the MBN signal increases (see the red line in Figure 15).

Multiple scans or passes per flank, performed at varying diameters, can be combined into a surface map. This provides the type of visual indication that Nital-etch users are accustomed to seeing, with the added benefit of objective, repeatable values (Fig. 16).

By comparing the relative MBN values to a quantitative method such as XRD the MBN values can be contextualized, and proper rejection/acceptance criteria can be developed. The most common method of developing rejection criteria involves comparing the MBN value to the maximum subsurface stress, measured via XRD, similar to the recommended practice in SAE ARP4462b. Such a comparison allows the user to choose an MBN value limit that corresponds to subsurface tensile stresses, or some other limit depending on the application and the design requirements for the component under test (Fig. 17).

Conclusion

Gears present challenges to many traditional testing methods both destructive and nondestructive. In cases where residual stress is critical, as is the case in shot-peened gears, verification of the shot-peening process via XRD can be fast enough to keep up with your production. This is especially true when utilizing state-of-the-art instruments such as the Xstress DR45.

Nearly all gears in precision applications have ground flanks. Sometimes they also have ground roots. Detecting grinding burn on these surfaces with maximum sensitivity and repeatability, all while avoiding costly scrap, is achievable using Magnetic Barkhausen Noise. Additionally, the method can be fully automated to provide measurable feedback for process control. ⚙️

stresstech.com

For Related Articles Search
nondestructive testing
 at www.geartechnology.com