INSTALLATION INSTRUCTIONS



Designer Cart Storage Shelf

SCSS



A brand of 🛱 legrand

DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Legrand AV Inc.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

Dimensions

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all accessories are properly assembled and installed using the instructions provided.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components stored both above and inside the SCSS accessory does not exceed 25 lbs (11.34 kg).

WARNING: Use this accessory only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

WARNING: Never operate this accessory if it is damaged. Return the accessory to a service center for examination and repair.

WARNING: Do not use this accessory outdoors.



WARNING: RISK OF INJURY TO PERSONS! Do not use this mounting system / accessory to support video equipment such as televisions or computer monitors.

--SAVE THESE INSTRUCTIONS--



TOOLS/PARTS REQUIRED FOR INSTALLATION



Assembly And Installation

Shelf Assembly

1. Insert storage shelf (A) into desired location on assembled designer cart. (See Figure 1)



Figure 1

- 2. (Optional) For security, install #10-32 x 3/8 security set screw (B) into hole on shorage shelf arm (A). (See Figure 2)
- **NOTE:** Rear cover must be removed to install security set screw (B).



Figure 2

Cable Management Options

- 1. Knockouts may be removed from back of shelf to use for cable routing. (See Figure 3)
- 2. Cables may be routed through three openings on upper edge of shelf compartment. (See Figure 3)







A brand of Liegrand

8800-003339 Rev00 ©2022 Legrand | AV www.legrandav.com 07/2022

Europe

Asia Pacific

- USA/International A 6436 City West Parkway, Eden Prairie, MN 55344
 - Ρ 800.582.6480 / 952.225.6000
 - **F** 877.894.6918 / 952.894.6918
 - A Franklinstraat 14, 6003 DK Weert, Netherlands
 - Ρ +31 (0) 495 580 852
 - F +31 (0) 495 580 845
 - A Office No. 918 on 9/F, Shatin Galleria 18-24 Shan Mei Street Fotan, Shatin, Hong Kong
 - **P** 852 2145 4099
 - **F** 852 2145 4477

