

15,000 km or 12 Months Service Schedule UC Series (RJ) 1.9L (RZ4E) & 3.0L(4JJ3) Diesel



5 000 km or 6 Months - UC Series (RJ) 1.9L (RZ4E) & 3.0L(4JJ3) Diesel Jul 2023

- 1. Refer to the Service Interval Guideline by Country for the correct Interval by kilometers or months, whichever occurs first.
- 2. This Service Schedule will have preference over the Owner's Manual and Warranty & Service Guide (Refer to updated date).
- 3. Refer to the Warranty and Service Guide for Severe Driving Conditions.

 Consult the Owner/Customer prior to any additional work being carried out as an additional cost will be charged for items not covered ι 	under warrant
---	---------------

Job Card No.	b Card No.: Date :			Model:													
Customer Name:VIN :						KM F	Readi	ng:									
Service Advis			Tech	nicia	n (Pr	int) :											
I = Inspection-a	after in	spection clean and correct, or replace as necessary S	ERVICE INTERVAL every KMs (x1000)	15	30	45	60	75	90	105	120	135	150	165	180		
R = Replace	A = A	djust T = Torque	or MONTHS, whichever occurs first	12	24	36	48	60	72	84	96	108	120	132	144		
L = Lubricate	C = C	lean S = Setting	S = Setting Labour hrs.				1,4	1,5	1,4	1,4	1,4	1,6	1,7	1,3	1,4	ок	NOT OK
		Engine Oil and Filter		R	R	R	R	R	R	R	R	R	R	R	R		
2		Fuel filter Fuel sedimentor for presence of water		R	R	R	R	R	R	R	R	R	R	R	R		
		Fuel leakage at tank, cap and pipes		I	ı	ı	I	ı	1	ı	1	ı	I	ı	I		
	5 6	Air filter element (I & R) and all air cleaner hose fitme Valve clearances - add 1.3 hrs for 4JJ3	nts for tightness (I)	-	R	-	R	-	R	-	R	-	R	-	R		\vdash
ENGINE		All engine drive belts for tension and damage and che	eck pulley condition	_			ı	_		-	ı			_	I		
		Run engine through operating range & check for exce		Ī	Ī	Ī	ı	ı	Ī	Ī	ī	Ī	Ī	ı			
	9	Coolant system for leaks (press.test rad. & cap) & che	eck coolant concentration (50% glycol)	ı	-	-	- 1	-	-	- 1	-	-	-	ı	I		
		Coolant concentration (50% glycol)		_	_	_	-	R	_	I	I	_	R	ı	I		
		Radiator core (check for foreign objects) and fan ope		1	<u> </u>	<u> </u>	l.	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	1	1	<u> </u>		<u> </u>
		Exhaust system for leaks and mountings for tightness			+	-	1		<u> </u>		<u> </u>	+	<u> </u> 	<u> </u>	\vdash		├—
		All hoses & pipes in engine compartment for tightness Brake pedal function, travel and free play	s or damage		<u> </u>	<u> </u> 	-	<u> </u>	<u> </u>	<u> </u>	H	H	÷	1			
		Brake fluid		i	R	÷	R	i	R	H	R	÷	R	i	R		<u> </u>
SERVICE	_	Front brake discs and pads for wear			I	İ	I	İ	I	i	I	İ	I	i	i		
BRAKE	17	Rear brake discs and pads for wear			_	_	-	-	_	I	I	_	_	-	I		
18 Brake pipes & hoses for leaks, loose connections or damage			damage	_	-	-	ı	-	_	ı	ı	_	Ι	ı	I		
TRANS. &		Automatic transmission fluid check for leaks		-	_	_	_		_	_	_	R	_		ı		<u> </u>
TRANSFER	20	Transfer case fluid * - add 0.15 hrs for replacement Universal joints & sliding sleeve	on 4x4	R L	L	L	R	L	L	R	L	L	R L	L	L		
PROPSHAFT		Prop shaft mounting and universal joints & sliding sle	eve for looseness and excessive wear		÷	÷		i	÷	1	i	÷	i	Ī	ī		
	23	Front axle fluid *- add 0.1 hrs for replacement on 43		R				- 1	- 1	R	- 1	- 1	- 1	1	1		
	24	Shift on the fly fluid*- add 0.1 hrs for replacement o		R	- 1	- 1	1	- 1	- 1	R	-1	-1	- 1	- 1	- 1		
FRONT/		Rear axle fluid - level and leaks			-	-	ı	-	_	R	ı	_	Ι	ı	I		
REAR AXLE					-	-	1	1	<u> </u>	!	1		ı	1			<u> </u>
		All axle shaft and housing for distortion or damage	VOTO.		+	I		1				+	<u> </u>	-	\vdash		├—
	28 Front drive axle CV joints, condition of rubber dust covers 29 Steering wheel play and function			÷	<u> </u>		<u> </u>	÷		H	÷	+	-	\dashv		 	
	30	Power steering fluid * - add 0.3 hrs for replacement		i	İ	İ	R	İ	İ	İ	R	İ	İ		R		
STEERING	31	Power steering pump, hoses, fittings and connections	- inspect for cracks and leaks *	Ι	Ι	Ι	Ι	_	Ι	- 1	ı	Ι	ı	_	ı		
	32	Steering rack and ball joint rubber boots				-	- 1			- 1			-	- 1	I		
	33	Wheel alignment inspection (to be offered to custome	er)		Rec	omme	nded e	every	service	e-cost	for cu	stome	r's acc	ount			<u> </u>
PARKING BRAKE	34	Parking brake function	Parking brake function		-	-	Ι	-	Ι	I	I	ı	I	-	I		
		Suspension front & rear - strut rubbers, bushes, tie-ro	d ends & link arms	I	ı	ı	ı	I	ı	- 1	- 1	ı	ı	ı	I		
CHASSIS &		Shock absorbers for leaks and looseness													\vdash		Ь—
SUSPENSION		Coil springs for damage Tightness of bolts and nuts on chassis and body			+	l I		-	+		-	÷	<u> </u>	-	\dashv		
		Cab mountings for looseness and damage				÷	i	i	÷	H	H	÷	÷	i			
		Tyre Pressure - Check and correct (incl. spare wheel))	I	Ī	Ī	ı	Ī	Ì	ı	ı	Ì	Ī	ı			
WHEELS	41	Inspect tyres & rims for damage (incl. spare wheel)		I	-	-	- 1	- 1	-	ı	I		Ι	ı	I		
WIILLES		Rotate tyres (if required) & torque wheel nuts as per		Τ	Т	Т	Т	Т	Т	Т	Т	T	Т	Т	Т		
		Wheel bearing (front & rear) - Inspect for bearing play								1	<u> </u>						Ь—
44		Vehicle systems - Check all ECUs for DTCs & reset s		ı		\ttach	roport	l to lo	h Card	1 at ev	orv se	rvice i	nterva	1			
	45 Extract DRM data & generate VDAS REPORT- Refer Bulletin 2304261630TRA0 – SB2309 46 Alternator output test (charging output voltage with all loads ON = 13.8V - 14.5V)		1	<u> </u>	I	Героп	I I	I	I al ev	l I	I	I	1			 	
ELECTRICAL		Battery electrolyte level and load test	ricado est Telev Tilev,		İ	İ	Ī	Ť	Ė	i	i	Ė	i	i	i		
EQUIPMENT		Check operation of all lights,hooter,instruments, aircon, radio, wiper blades & washers		Ι		_			_	I	I	_	_	-			
	49				R	-	R	-	R	-	R	-	R	-	R		
		Airbag system self test and warning light function		1	l	!	- 1	<u>!</u>	!	<u> </u>	<u> </u>	!	!	ı	<u> </u>		<u> </u>
		Seatbelts function and damage	nastian abaut	1	\	l nh con	l v of C	hoot t	l lob (Cord	 	1	ioo int	l on/ol			<u> </u>
BODY		Inspect chassis and body for corrosion - complete ins Door, tailgate and hood lock/striker to Check/Adjust/O		,	Alla	лі сор	y UI S	i ieet to	ו מטט נ	oara a	ıı ever	y serv	ice int	ıvaı	$\overline{}$		
5051		Pollen filter	biean/Lubricate ii requireu	<u> </u>	R	÷	R	1	R	 	R	+	R	1	R		
		Air conditioner drain pipe for drainage		i	ı,	i	I	i	ı.	i i	ı,	Ť	ı.	i	i l		
SAFETY		Check for open RECALLS or SERVICE CAMPAIGNS	3		Atta		py of I		Job C	ard at	every	servi	ce inte	rval			
TESTING		Road test		I	Ī	Ī	Ī	Ī	Ī	Ī	Ī	Ī	Ī	Ī	П		
	* Who	re fitted															

Customer Signature Date

Technician Signature

4JJ3-3.0 & RZ4E-

Issue date Oct 2023

Document No.

I was informed of the service cost & additional items that needs attention.

I hereby confirm that all items have been checked and and rectifed where required.



15,000 km or 12 Months Service Schedule UC Series (RJ) 1.9L (RZ4E) & 3.0L(4JJ3) Diesel



5 000 km or 6 Months - UC Series (RJ) 1.9L (RZ4E) & 3.0L(4JJ3) Diesel Jul 2023 PLEASE NOTE:

- 1. Refer to the Service Interval Guideline by Country for the correct Interval by kilometers or months, whichever occurs first.
- 2. This Service Schedule will have preference over the Owner's Manual and Warranty & Service Guide (Refer to updated date).
- 3. Refer to the Warranty and Service Guide for Severe Driving Conditions.

4. Consult the Owner/Customer prior to any additional work being carried out as an additional cost will be charged for items not covered.	red under warranty
---	--------------------

Job Card No.: Model : Model :																	
Customer Name:VIN :					KM F	Readi	ng:										
Service Advisor :																	
I = Inspection-	after in:	spection clean and correct, or replace as necessarySEF	RVICE INTERVAL every KMs (x1000)	195	210	225	240	255	270	285	300	315	330	345	360		
R = Replace	A = A	djust T = Torque	or MONTHS, whichever occurs first	156	168	180	192	204	216	228	240	252	264	276	288		
L = Lubricate	C = C	lean S = Setting	Labour hrs.	1,4	1,4	1,5	1,4	1,3	1,8	1,4	1,4	1,3	1,4	1,3	1,4	ок	NOT OK
	1	Engine Oil and Filter		R	R	R	R	R	R	R	R	R	R	R	R		Ū.
		Fuel filter		R	R	R	R	R	R	R	R	R	R	R	R		<u> </u>
		Fuel legislage at task, can and pines			-		1	-	ı	+	<u> </u>	<u> </u>		+			<u> </u>
		Fuel leakage at tank, cap and pipes Air filter element (I & R) and all air cleaner hose fitmen	te for tightness (I)	-	R	1	R	-	l R	1	R	l I	R	1	R		├
	6	Valve clearances - add 1.3 hrs for 4JJ3	ts for tigritiless (i)	-	-	-	A	-	-		A	-	-	-	A		
ENGINE	7	All engine drive belts for tension and damage and chec	ck pulley condition	_	_	ı	Ι	_	_	ı	-	-	-	1	-		
	8	Run engine through operating range & check for exces		I	I	Ι	ı	ı	ı	ı	I	-	Ι	I	Ι		
	9	Coolant system for leaks (press.test rad. & cap) & che	ck coolant concentration (50% glycol)	I	- 1	I	ı	ı	- 1	ı	I	ı	- 1	- 1	ı		
		Coolant concentration (50% glycol)		_		R	- 1	1	-	-	R				- 1		<u> </u>
	11	Radiator core (check for foreign objects) and fan opera				l.			!	<u> </u>	<u> </u>						Ь—
		Exhaust system for leaks and mountings for tightness of	ŭ	_		l I	I			-	<u> </u>	+		<u> </u>	-		
	13 14	All hoses & pipes in engine compartment for tightness Brake pedal function, travel and free play	or damage	+	1	<u> </u>	+	<u> </u>	<u> </u>	+	H	1	÷	+			
		Brake fluid		÷	R	÷	R	<u> </u>	R	÷	R	i	R	<u> </u>	R		
	SERVICE 16 Front brake discs and hads for wear					i	Ī	i		i	ı	i		i	-1		
BRAKE	BRAKE 17 Rear brake discs and pads for wear		ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	-	ı			
18 Brake pipes & hoses for leaks, loose connections or damage		ı	- 1	- 1	- 1	-	- 1	-	ı	- 1	- 1	1	- 1				
TRANS. &	19	utomatic transmission fluid check for leaks				-	ı	ı	R	-	ı	- 1			- 1		<u> </u>
TRANSFER	20	Transfer case fluid * - add 0.15 hrs for replacement of	on 4x4	R		-	R			R		4	R	4	4		⊢
PROPSHAFT		Universal joints & sliding sleeve Prop shaft mounting and universal joints & sliding slee	vo for loosanass and avaassiya waar	L	L	L	L	L	L	L	L	L	L	L I	L		
	23	Front axle fluid *- add 0.1 hrs for replacement on 4x4		R			-		_	R	_		-		-		
	24	Shift on the fly fluid*- add 0.1 hrs for replacement on		R	Ť	Ť	Ť		Ť	R	i	Ť	Ť	÷			
FRONT/	25	Rear axle fluid - level and leaks		R	_	ı	ı	Ι	_	R	Ι	- 1	ı	- 1	Ι		
REAR AXLE	26	Shift on the fly & rear diff lock operation test *		I	- 1	I	ı	ı	- 1	ı	I	ı	- 1	- 1	ı		
	27 All axle shaft and housing for distortion or damage		I	ı	- 1	- 1	1	ı	- 1	ı	- 1	- 1	- 1	- 1			
	28	ront drive axle CV joints, condition of rubber dust covers				<u> </u>			!	<u> </u>	<u> </u>						Ь—
	29 30	Steering wheel play and function		_		ı	I R	_	_	_	l R		-		R		
STEERING	31	Power steering fluid * - add 0.3 hrs for replacement Power steering pump, hoses, fittings and connections	inspect for cracks and leaks *	_	_	<u> </u>		_	_	-				+	ı		
	32	Steering rack and ball joint rubber boots				i	ı			i	i	Ť	Ť	Ť	İ		
	33	Wheel alignment inspection (to be offered to customer)		Rec	omme	nded e	every	service	e-cost	for cu	stome	r's acc	ount			
PARKING BRAKE	34	Parking brake function		_	1	I	1	_	1	I	-	1	-	ı	1		
	35	Suspension front & rear - strut rubbers, bushes, tie-rod	ends & link arms	-	Ι	Ι	ı	ı	Ι	ı	Ι			T	Ι		
CHASSIS &	36	Shock absorbers for leaks and looseness		I	ı	Ι	ı	ı	ı	ı	I	ı	ı		ı		
SUSPENSION	37	Coil springs for damage			-	Ι	ı	ı	ı	ı	_	ı	ı				
		Tightness of bolts and nuts on chassis and body				_!_	!		-	!	1			<u> </u>			⊢
		Cab mountings for looseness and damage Tyre Pressure - Check and correct (incl. spare wheel)				<u> </u> 	1			<u> </u>	<u> </u>	-		<u> </u>	-		
		Inspect tyres & rims for damage (incl. spare wheel)			-	-	-			-	+	-	+	<u> </u>	-		
WHEELS		Rotate tyres (if required) & torque wheel nuts as per s	pec - Refer Bulletin GEN-2015-09	T	T	T	T	T	T	T	T	Ť	Ť	Ť	T		
		Wheel bearing (front & rear) - Inspect for bearing play	Pool. 110101 Danielli	i	İ	i	Ī	i	Ī	i	i	i	i	i	İ		
	44	Vehicle systems - Check all ECUs for DTCs & reset se	ervice interval *	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	-	ı		
	45	Extract DRM data & generate VDAS REPORT- Refer	Bulletin 2304261630TRA0 - SB2309		- /	Attach	report	to Jo	b Card	at ev	ery se	rvice i	nterva	ı			
ELECTRICAL	46	Alternator output test (charging output voltage with all I	oads ON = 13.8V - 14.5V)	I	ı	I	ı	ı	ı	ı	I	-	- 1	ı	- 1		<u> </u>
EQUIPMENT	OUIPMENT 47 Battery electrolyte level and load test				Ι.		<u> </u>	-	Ι.	<u> </u>	<u> </u>		<u> </u>			Ь—	
		Check operation of all lights, hooter, instruments, airco	n, radio, wiper blades & washers	1	R	<u> </u>	l R	1	I R	-	R	- !	l R		R		
		Airbag system self test and warning light function		_	I.	<u>-</u>	I	_	I	-	I	-	I	-	I		
		Seatbelts function and damage			+	÷	-			<u> </u>	÷	÷	\vdash	÷	<u> </u>		
		Inspect chassis and body for corrosion - complete insp	ection sheet	•	Atta	ch cop	y of Sl	neet to		Card a	at ever	y serv	ice int	erval	•		
BODY		Door, tailgate and hood lock/striker to Check/Adjust/Cl		ı	ı	ı i		1	ı	1	I	1	1	ı	ı		
		Pollen filter		I	R		R	ı	R		R		R		R		
		Air conditioner drain pipe for drainage		I	Ī	Ī	I	I	I.	I	Ī	Ī	Ī	Ī	I		
SAFETY		Check for open RECALLS or SERVICE CAMPAIGNS			Atta	ch cop	y of Sl	neet to	Job (Card a	at ever	y serv	ice int	erval			<u> </u>
TESTING		Road test		ı	I	I	I	I	I	ı				- 1	I		
	vvne	re fitted															

Customer Signature Date Technician Signature

I hereby confirm that all items have been checked and and rectifed where required.

Issue date Oct 2023 Document No. 4JJ3-3.0 & RZ4E-1.9

I was informed of the service cost & additional items that needs attention.

Attach one copy to <u>Customer's Invoice</u> Attach one copy to <u>Job Card</u>



15,000 km or 12 Months Service Schedule UC Series (RJ) 1.9L (RZ4E) & 3.0L(4JJ3) Diesel



PLEASE NOTE:

5 000 km or 6 Months - UC Series (RJ) 1.9L (RZ4E) & 3.0L(4JJ3) Diesel Jul 2023

- 1. Refer to the Service Interval Guideline by Country for the correct Interval by kilometers or months, whichever occurs first.
- 2. This Service Schedule will have preference over the Owner's Manual and Warranty & Service Guide (Refer to updated date).
- 3. Refer to the Warranty and Service Guide for Severe Driving Conditions.

4. Consult the Owner/Customer	r prior to any additional work being	carried out as an additional cost will be char-	ged for items not covered under warranty
-------------------------------	--------------------------------------	---	--

Job Card No.:	b Card No.: Date :			Model :													
Customer Nar	stomer Name: VIN :					KM F	Readi	ng:									
Service Advisor :																	
I = Inspection-a	after ins	spection clean and correct, or replace as necessary SE	RVICE INTERVAL every KMs (x1000)	375	390	405	420	435	450	465	480	495	510	525	540		
R = Replace	A = A	djust T = Torque	or MONTHS, whichever occurs first	300	312	324	336	348	360	372	384	396	408	420	432		
L = Lubricate		Ÿ	Labour hrs.	1,6	1,4	1,6	1,4	1,3	1,7	1,4	1,4	1,3	1,4	1,5	1,4	ок	NOT OK
		Engine Oil and Filter		R	R	R	R	R	R	R	R	R	R	R	R		<u> </u>
		Fuel filter		R	R	R	R	R	R	R	R	R	R	R	R		—
ŀ		Fuel sedimentor for presence of water Fuel leakage at tank, cap and pipes		-	-	 	- !	<u> </u>	-			-			- 1		
		Air filter element (I & R) and all air cleaner hose fitme	nts for tightness (I)	<u> </u>	R		R	<u> </u>	R	i	R	÷	R	÷	R		
	6	Valve clearances - add 1.3 hrs for 4JJ3	its for tigritiless (i)	-	-		A	-	-		A	-	-	-	A		
ENGINE		All engine drive belts for tension and damage and che	ck pulley condition		1		î	1	_		î			1	î		
		Run engine through operating range & check for exce		Ť	i	i	i	i	i	Ė	i	Ė	Ť	Ė	i		
		Coolant system for leaks (press.test rad. & cap) & che		Ť	Ī	Ī	ı	Ī	ı	ı	Ī	ı	Ť	Ī	ı		
ľ		Coolant concentration (50% glycol)	(0,7 /	R	ı	ı	ı	- 1	R	ı	ı	ı	ı	R	ı		
	11	Radiator core (check for foreign objects) and fan oper	ation	- 1	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı		
	12	Exhaust system for leaks and mountings for tightness	or damage	-	ı	ı	ı	I	ı	ı	ı	ı	ı	ı	ı		
	13	All hoses & pipes in engine compartment for tightness	or damage		ı	ı	ı	I	ı	-	I	- 1	I	ı	ı		
	14	Brake pedal function, travel and free play		- 1	_		- 1	- 1	- 1		-			ı	-		
SERVICE	15	Brake fluid		- 1	R	- 1	R	- 1	R	- 1	R	- 1	R	- 1	R		
BRAKE	BRAKE 16 Front brake discs and pads for wear				- 1	- 1	ı	- 1	ı	ı	ı	ı	- 1	- 1	- 1		
	17 Rear brake discs and pads for wear					ı	I	ı	ı	ı	I	ı	ı	ı	ı		—
		Brake pipes & hoses for leaks, loose connections or damage				-	-		- 1	1	1		- 1	- 1	-		
TRANS. &		Automatic transmission fluid check for leaks			_	R	- 1		ı	- (_	_ (_	R		<u> </u>
TRANSFER	20	Transfer case fluid * - add 0.15 hrs for replacement	on 4x4	R		4	R			R	+	+	R		4		-
PROPSHAFT		Universal joints & sliding sleeve Prop shaft mounting and universal joints & sliding slee	wa for loosoness and excessive wear	L	L	L	L	L	L	L	L	L	L	L	L		
	23	Front axle fluid *- add 0.1 hrs for replacement on 4x		R	-	-	_	_		R		_			1		
ŀ	24	Shift on the fly fluid*- add 0.1 hrs for replacement or		R		÷		÷		R	÷	÷	÷	÷			
FRONT/		Rear axle fluid - level and leaks	1 474	R	i	ı			_	R	i		i	i			
REAR AXLE				Ť	i	Ī	Ī	T	Ī	ī	i i	i		Ī	Ī		
İ	27 All axle shaft and housing for distortion or damage				I	ı	- 1	- 1	ı	1	ı	1	- 1	- 1	1		
İ		Front drive axle CV joints, condition of rubber dust covers			ı	Ι	ı	Τ	ı	ı	ı	ı	Т	-	ı		
	29	Steering wheel play and function			ı	ı	ı	- 1	ı	-	ı	ı	ı	ı	ı		Ī
	30	Power steering fluid * - add 0.3 hrs for replacement		1	- 1	-	R	- 1	- 1	- 1	R	- 1		- 1	R		
STEERING	31	Power steering pump, hoses, fittings and connections	- inspect for cracks and leaks *	- 1	-	-	- 1	- 1	- 1		-	-		ı	- 1		
	32	Steering rack and ball joint rubber boots		-	-	-	ı	- 1	ı	-	ı	ı		- 1	-		
	33	Wheel alignment inspection (to be offered to custome	r)		Rec	omme	nded e	very s	service	e-cost	for cu	stome	r's acc	count			
PARKING BRAKE	34	Parking brake function		1	I	I	I	I	1	ı	1	1	1	I	I		
	35	Suspension front & rear - strut rubbers, bushes, tie-roo	d ends & link arms		ı	ı	ı	- 1	ı	ı	ı	ı	ı	ı	ı		
01140010.0	36	Shock absorbers for leaks and looseness		- 1	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı		
CHASSIS & SUSPENSION	37	Coil springs for damage		-	ı	ı	ı	I	ı	ı	ı	ı	ı	ı	ı		
SUSPENSION	38	Tightness of bolts and nuts on chassis and body		-	_	-	-	-	-		ı		- 1		-		
	39	Cab mountings for looseness and damage		-	_	-	-	-	-		ı		- 1		-		
	40	Tyre Pressure - Check and correct (incl. spare wheel)		-	- 1	- 1	ı	- 1	ı	-	ı	-	- 1	- 1	- 1		
WHEELS		Inspect tyres & rims for damage (incl. spare wheel)		- 1	- 1	- 1	ı	- 1	ı	ı	ı	ı	- 1	- 1	- 1		
		Rotate tyres (if required) & torque wheel nuts as per		T	Т	T	T	T	Т	Т	T	Т	Т	T	T		<u> </u>
		Wheel bearing (front & rear) - Inspect for bearing play		1	-	-	- 1		- 1	1	1	-	- 1	- 1	-		
44 Vehicle systems - Check all ECUs for DTCs & reset service interval *		ı	<u> </u>	1		4- 1-	- C	1 -4			-4		ı		-		
		Extract DRM data & generate VDAS REPORT- Refer		_	 '	Attach	героп	10 JOI	Carc	atev	ery se	rvice	nterva				
ELECTRICAL		Alternator output test (charging output voltage with all loads ON = 13.8V - 14.5V)		+	-	-	- 1	-	- !	-	<u> </u>	-		-	-		
EQUIPMENT		Battery electrolyte level and load test Check operation of all lights, hooter, instruments, aircon, radio, wiper blades & washers		+	<u> </u>	<u> </u>	ı	_	<u> </u>		+	-	-	 			
}		Remote key battery	on, radio, wiper blades & washers	_	R	-	R		R	-	R	-	R		R		
ŀ		Airbag system self test and warning light function		_	I	-	I	-	ı		I	-	I	<u> </u>	I		
		Seatbelts function and damage		+	-	1	ı	÷	1	-	H	-	+	-			
ŀ		Inspect chassis and body for corrosion - complete ins	pection sheet	- 1	Atta	ch cop	v of S	neet to	Joh (Card s	t ever	v serv	ice int	erval			
BODY		Door, tailgate and hood lock/striker to Check/Adjust/C			I	σορ	, 5, 5	1	1	I	1	1	1	I			
200.		Pollen filter	ioan, Eubiloato ii roquileu	÷	R	-	R		R	-	R	-	R	-	R		
ŀ		Air conditioner drain pipe for drainage			ı.		ı,		1	Ė	ı,	Ė		i	-:\ 		
SAFETY		Check for open RECALLS or SERVICE CAMPAIGNS		-	Atta	ch cop	y of S	neet to	Job (Card a	at ever	y serv	ice int	erval			
TESTING		Road test		1	ı	1		1	ı	ı	ı	ı	1	ı	ı		
I		e fitted	1								•						

Technician Signature

I hereby confirm that all items have been checked and and rectifed where required.

Issue date
Oct 2023

Document No.

4JJ3-3.0 & RZ4E1.9

I was informed of the service cost & additional items that needs attention.

Date

Customer Signature

Attach one copy to <u>Customer's Invoice</u> Attach one copy to <u>Job Card</u>

Corrosion Inspection Sheet mu-X (RJ01)



PLEASE NOTE: Copy to be attached to Job Card

Job Card No.	Date:	Model:
Customer Name:	Km.:	VIN :
Service Consultant name:	Technician name:	
Bodywork Inspection		
Vehicle OK Comments	s	
Yes No		
Vehicle Repaired		
Yes No No	DEALER'	'S STAMP
Accident / Bodywork damage	A	ND
repaired to factory standard		
Yes No	SIGNA	ATURE
MARK TEST F	RESULTS USING RELEVANT SYN	/IBOL
STONE THROW	O DENT / BUMP	BODYWORK DAMAGE
+ SCRATCH THE DIAGRAI	# PAINTWORK DAMAGE M IS REPRESENTATIVE OF ALL MODEL SERIE	SEAL UNDERBODY