

Advantage**360**

KINESIS



KB360

Quick Start Guide

This Quick Start Guide is designed to get you up and running with keyboard basics. For additional details and full programming instructions please read the User's Manual and consult the other support resources before embarking on this journey.

All Support Resources: kinesis.com/support/kb360



Visit the Kinesis Official YouTube channel for short tutorial videos

Keyboard models covered by this guide include all KB360 series keyboards (KB360-xxx).

© 2022 by Kinesis Corporation. All rights reserved.
KINESIS is a registered trademark of Kinesis Corporation.
ADVANTAGE360, CONTOURED KEYBOARD, SMARTSET, and V-DRIVE are trademarks of Kinesis Corporation.

WINDOWS, MAC, MACOS, LINUX, ZMK and ANDROID are property of their respective owners.

Proudly designed and hand-assembled in the USA since 1992.

Shop for Accessories: kinesis.com/products



Warning

The Advantage360 is not a medical treatment. Please consult your doctor if you experience pain while using a keyboard and discontinue use immediately.

In the Box

- Keyboard (KB360-XXX)
- Main Cable (USB-C to USB-A)
- Link Cable (USB-C to USB-C)
- Bridge Connector
- Extra Keycaps & Keycap Removal Tool

System Requirements

- Keyboard: Computer with full-size USB-A port and Windows 7-12®, macOS®, Linux®, or Chrome® operating system
- SmartSet App: Windows or macOS

Getting Started

Start by connecting the “Link Cable” to the two innermost ports on each keyboard module. Then connect the USB-C end of the “Main Cable” to the outermost port on the right module. Finally, connect the USB-A end of the Main Cable to your computer.



Installation

Depending on your operating system, your computer may prompt you through a series of brief setup steps when you first connect the keyboard. *Note: The Advantage360 is plug-and-play and does not require any special drivers or software for basic use.*

Ergonomics

The Kinesis contoured keyboard has stood the test of time since its first introduction in 1992. The Advantage360 takes those same core design principles and adds adjustable separation, rotation, and tenting to suit any body type.

Learn More: kinesis.com/solutions/keyboard-risk-factors

Separation and Rotation

The most ergonomic typing position is one in which your hands are in line with your arms for “straight” wrists. This can be achieved by separating the modules to shoulder-width, by rotating the modules “outward”, or any combination of the two. New users should start with the modules closer together, and experiment with separation and rotation to see what orientation feels most natural.



Optional Bridge Connector

For those who want to recreate the classic separation of our original contoured keyboard, or those who just aren't ready to make the move to a fully split keyboard, simply snap the Bridge Connector onto the keyboard base.

Warning: The Bridge Connector is NOT designed to support the weight of the keyboard!!!



Adjustable Tenting

The Advantage360 features three adjustable “tenting” heights to reduce forearm pronation. Depress the button on the underside of each module and raise/lower the module to the desired height. The lowest setting corresponds to the original contoured keyboard height, but users can go up from there to find the perfect position.



Customizing Keycaps


Extra keycaps like macOS modifiers and “blanks” are included to support keyboard customization. Use the keycap removal tool to grasp the sides of a keycap and gently pull straight up to remove. Carefully align the new keycap over the stem of the key switch and press down gently. *Note: Each keycap has a different height and slope so it may not be suitable for every location on the keyboard.*

6 Indicators LEDs

The Advantage360 features six Indicator LEDs that display important keyboard settings. The default assignments are shown below, but each LED can be customized to suit your preferences using the SmartSet App or Direct Programming.

Caps Lock | Profile | Layer

Num Lock | Scroll Lock | Layer



Default Profile LED Color

- 0: Off
- 1: White
- 2: Bright Blue
- 3: Green
- 4: Red
- 5: Blue
- 6: Yellow
- 7: Orange
- 8: Green-Blue
- 9: Pink

Default Layer LED Color

- Base: Off
- kp: White
- fn: Blue

Note: Power users can access two additional fn layers (fn2 and fn3) via the SmartSet App or Direct Programming if desired.

Optional Palm Pads

If you purchased the all-new Palm Pads separately, simply identify the correct side and drop them into place. The magnets will automatically center them on the keyboard. Clean by wiping with a small amount of lightly soapy water as needed.



Default Keyboard Layout

The Advantage360 may look intimidating at first, but the layout is designed to work with your body and most keys are accessed with the same fingers touch-typists are accustomed to using.

- Concave keywells place alphanumeric keys within easy reach
- Heavily-used editing keys are positioned under your thumbs
- F1- F12 are accessed by **holding** either of the two "fn" layer keys
- The numeric keypad is accessed by **tapping** the "kp" layer key
- 4 blank "hotkeys" are available for macros or custom key actions
- Onboard programming commands are triggered by key combinations initiated with the "SmartSet" Key

3 Default Layers

Each key can perform multiple actions depending on which "layer" is active on the keyboard. The layer LEDs will illuminate when you move away from the base layer. By default, most keys perform the same action in all three layers. If a key performs multiple actions, the keycap will feature a second or third legend on its front face.

1) Base Layer: In the base layer, each key performs its primary action, which is legended on the **top** of the keycap.

2) kp Layer: Tap the "kp" key on the left module to access the kp layer, and tap it again to return to the base layer. Kp layer actions are legended on the **lower right corner** of the keycap.

3) fn Layer: Press and hold either of the "fn" keys with your pinky to temporarily access the fn layer, and release to return to the baselayer. Fn layer actions are legended on the **lower left corner** of the keycap.

10 Available Profiles

The Advantage360 features 10 onboard Profiles. The factory-default profile, Profile 0, is non programmable to prevent accidental programming by novice users. If you don't plan to customize the keyboard, this is the perfect profile for you.

If you do plan to customize the keyboard, you'll need to first switch to one of the 9 programmable profiles. Switching between profiles is easy using the convenient onboard shortcut and the number row.

Onboard Programming

The Kinesis SmartSet Engine is designed to let you quickly and easily re-program the keyboard layout without downloading any software by using the SmartSet Key in conjunction with the 4 Hotkeys. Remember to toggle to one of the 9 programmable profiles first, and then follow the steps below. *Note: Consult the full User Manual for additional details.*



Remapping

To “Remap” any key on the Advantage360 to a new location:

- 1) Press and hold the SmartSet Key, then tap the Remap Key
- 2) First select the source key (i.e, the action you want to copy)
- 3) Then select the physical destination key

Remap:  + Remap Key

Note: Onboard remapping does not swap keys, it just duplicates the action. To swap keys, repeat the remapping process and press the desired keys in the opposite order. Desired key actions which do not exist in the default layout can be added to any key or layer via the SmartSet App or Direct Programming.

On-the-Fly Macro Recording

To assign a “macro” to any key or key combo on the Advantage360:

- 1) Press and hold the SmartSet Key, then tap the Macro Key
- 2) First select the macro trigger key(s). If you wish to trigger your macro with a key combination, press and hold the desired modifier key(s) and then tap the primary non-modifier trigger key.
- 3) Once you have designated your trigger key(s), the keyboard will start recording all subsequent keystrokes for your macro (300 max).
- 4) When you have finished recording your macro, tap the SmartSet Key to stop recording. The macro will save to the active Profile.

Record Macro:  + Macro Key

Advanced Programming

For Advantage360 users who want to go beyond basic onboard programming, there are host of additional features and and special actions which can be accessed through the SmartSet App or by Direct Programming the keyboard's configuration files.

**Mouse Clicks/Movement | Tap-and-Hold | Multi-Modifiers
Layer Toggle/Shifting | fn2 & fn3 Layers | Media Keys
Macro Playback Tools | Indicator LEDs | Special Key Actions**

The All-New SmartSet App

The SmartSet App provides an easy-to-use graphical interface for Windows or Mac users. Use the App to customize the keyboard's settings, layout (including rapid Dvorak & Colemak configurations), and indicator LEDs.



Download the App: kinesis.com/support/kb360/#smartset-app

Simply launch the SmartSet App and follow the prompts to connect the keyboard's v-Drive to your computer. Save your changes in the App and then use the Refresh shortcut to push those changes to the keyboard. Then disconnect the v-Drive to resume normal operation.

Connect/Disconnect v-Drive:  + v-Drive Key

Refresh Keyboard :  + Refresh Key

Direct Programming

Power users have the option of directly programming the keyboard by editing the simple text configuration files found on the v-Drive. Read the Direct Programming guide for syntax rules and tokens, and proceed with caution.

Learn More: kinesis.com/support/kb360/#manuals

Additional Power Users Features

There are a variety of additional features and onboard shortcuts which are described in full detail in the User Manual.

**NKRO | Firmware Update | Program Lock | Status Report
Hard Reset | Soft Reset | Reformat v-Drive**