


Threaded Inserts to allow fitting to trolley or ceiling adapter

Description		PzX9 Universal Flat Mount 1000 X 600			
UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS		Mod Date	20/12/2016	REVISION	See Below - Fixings Required
		Drawn Date:	04/02/2016		
SURFACE FINISH: Powder Coated				A-014	Fixing Kit Type 6
DRAWN Ricky Clark		Material			
Unicol Engineering Green Road Oxford OX3 8EU		Gauge			DWG NO.
					PZX9U
					A4

Bend Tool

All Fixings must be approved
by a builder or architect
and these are only shown for illustrational purposes



Ensure that the walls the load - (screen including all bracketry and peripherals).

1. Mount the bracket to the screen and measure off to establish the location of the mount fixing points
2. Place the back plate (2) at the location required and mark though the fixing locations, Ideally fit (1) one location point then pilot drill through the remaining ones after confirmation it is in the correct location and is level.
3. Pass any cables though (3) making certain that they will not be trapped by any moving parts
4. Fit the arms (5) to the screen using the supplied fixings (4)
5. Lift the screen with the arms attached on to the side fixings using an assistant to help with the load and fit the cables in place

Description		Pzx9 Universal Flat Mount 1000 X 600			
UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS	Mod Date	20/12/2016	REVISION	Bend & Machine Number	
	Drawn Date:	04/02/2016	A-014		
SURFACE FINISH: Powder Coated	DRAWN Ricky Clark		Material	DWG NO. PZX9U	
	Unicol Engineering Green Road Oxford OX3 8EU		Gauge		
Bend V Tool	WEIGHT: 12.30		Kg	SCALE:1:10	DO NOT SCALE DRAWING
				SHEET 2 OF 2	A4